

ioLogik 2500 Series User Manual

Version 7.1, May 2023

www.moxa.com/products



ioLogik 2500 Series User Manual

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

Copyright Notice

© 2023 Moxa Inc. All rights reserved.

Trademarks

The MOXA logo is a registered trademark of Moxa Inc.
All other trademarks or registered marks in this manual belong to their respective manufacturers.

Disclaimer

- Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.
- Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.
- Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.
- This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

Technical Support Contact Information

www.moxa.com/support

Table of Contents

1. Overview	5
ioLogik 2500 Overview	5
Appearance	5
Dimensions Diagram.....	6
Package Checklist.....	6
Product Features	7
I/O Channels Available on ioLogik 2500 Models	7
Communication Interface	7
ioLogik 2500 Specifications	7
2. Installation.....	8
Hardware Installation	8
Installing the ioLogik 2500 on a DIN Rail.....	8
Removing the ioLogik 2500 from a DIN Rail.....	9
Powering on the ioLogik 2500.....	10
Grounding the Unit	10
Installing a microSD Card and SIM Cards (cellular models only)	10
I/O Terminal Pinouts	11
I/O Wiring Diagrams	11
I/O Wiring	11
DI Channel	11
DO Channel (Sink Type).....	12
AI Channel	13
LED Indicators.....	13
Daisy-Chaining for I/O Expansion	14
Reset to Factory Defaults.....	15
Network Installation	15
Ethernet Communication	15
TCP/IP Settings.....	15
Serial Communication	16
Software Installation—IOxpress Utility.....	16
System Requirements	17
Installing IOxpress	17
3. The IOxpress Utility.....	18
Application Interface	18
Main Screen.....	18
Menu Bar	18
Using IOxpress.....	19
Configuration Flowchart.....	19
Configuration Library	19
Device Library.....	19
4. Configuration Library.....	20
Introduction	20
Saving Configurations as a Project.....	20
Adding an ioLogik 2500 Device to a Project	20
Adding E1200 I/O Expansion Modules to a Project	21
Duplicate Device Configuration for Mass Deployment	22
Setting Up a Device	23
Settings Tab	23
System	23
Security	24
Network	26
I/O	28
AOPC	38
SNMP.....	40
Modbus/TCP Slave.....	40
Modbus/TCP Master	41
Serial Port (Port1/Port2).....	44
Data Logging	48

Click&Go Plus.....	51
Click&Go Plus Tab.....	51
Click&Go Plus Simulator Tab	52
Peer-to-Peer Tab	52
General Settings	53
Peer-to-Peer Rule Settings	53
5. Device Library.....	55
Introduction	55
Auto-Searching for Online Devices	56
First Time Searching for Devices	56
Conducting another Search for Online Devices	56
Deployment	58
Update Configuration to Device	60
Get Configuration from Device	60
Update Firmware.....	60
Set Device Date & Time	61
Retrieve System Log.....	62
Restart Device	62
Load Factory Default.....	62
Change IP Address	62
Change Device Name	62
Web Console	62
Web Console Functions.....	63
User Interface Introduction.....	63
System Information Panel	63
Menu Panel and Web Pages	64
6. Cellular Network Setup and Configuration (for cellular models).....	66
IOxpress Settings for a Cellular Network.....	66
Select Network Interface.....	66
Cellular	68
Cellular Network Connection	74
MX-AOPC Server (for SCADA/HMI users).....	74
With DDNS (for SCADA/HMI users).....	75
Moxa Cellular Data Access Utility (for mobile devices/PCs).....	75
7. Wireless LAN Network Setup and Configuration (for wireless LAN models)	77
Deploying the ioLogik 2500-WL1.....	77
IOxpress Settings for a Wireless LAN Network	78
Wireless LAN	78
A. Network Port Usage.....	83
B. Modbus/TCP Default Address Mappings	84
ioLogik 2512 Series Modbus Address and Register Map.....	84
ioLogik 2542 Series Modbus Address and Register Map.....	85
C. RESTful API Default Address Mappings.....	86
API List	86
Response Code.....	90

1. Overview

The ioLogik 2500 is a smart remote I/O product with unique hardware and software designs, making it an ideal solution for a variety of industrial data acquisition applications. The ioLogik 2500's hardware design includes a 4-port unmanaged Ethernet switch and 2 serial ports, enabling the ioLogik 2500 to seamlessly connect to a variety of field devices. One of the Ethernet ports can be used to link to 8 daisy-chained ioLogik E1200 expansion modules to provide more than 100 channels. The ioLogik 2500 acts as the "head" unit, with Click&Go Plus logic used to control the entire I/O array. Most importantly, the ioLogik 2500's single IP is all that's required to connect the entire I/O array to your network, providing the perfect solution for industrial field sites that have an insufficient number of IP addresses.

For cellular connections, the ioLogik 2500 supports Moxa's patented MX-AOPC Server with push communications technology, and provides an economical solution for accessing multiple remote I/O devices connected to the same private IP network, which itself links to the outside world over a cellular connection using dynamic IP addresses.


ioLogik 2500 Overview




The ioLogik 2500 combines a remote I/O device and data logger into one box, dramatically reducing the amount of effort required to integrate devices from multiple vendors. I/O and serial data can be logged onto a Micro SD card (supports cards with up to 32 GB of storage space), and the ioLogik 2500 can be programmed with Moxa's convenient Click&Go™ Plus control logic, which can be used to easily construct customized control systems. As a rugged industrial device, the ioLogik 2500 operates reliably at a wide range of temperatures, and is well suited for hard-to-wire remote monitoring and alarm applications at unmanned sites like riversides and pipelines.

Appearance

Top View




Front View



Dimensions Diagram

Units: mm (in)



Package Checklist

The ioLogik 2500 is shipped with the following items:

- ioLogik 2500 device
- 2 RJ45-to-DB9 connection cables (CBL-RJ45M9-150)
- 1 antenna (only for wireless models)
- Quick installation guide (printed)



NOTE

Please notify your sales representative if any of the above items are missing or damaged.

Product Features

- Supports cellular (HSPA/GPRS), Ethernet, and serial communication (ioLogik 2500-HSPA/GPRS only)
- New Click&Go Plus logic provides powerful front-end intelligence
- 4-port unmanaged switch built in for linking to Ethernet devices
- Optimized I/O expansion port for daisy chaining up to 8 ioLogik E1200 units
- 2 serial ports (RS-232/422/485) for connecting field devices
- Built-in data logger supports an FTP server/client and microSD™ card with up to a 32 GB
- Transforms Modbus RTU into Modbus TCP or Active Tags
- Active communication with patented MX-AOPC UA Server
- Smart alarm management: Email, SNMP traps, TCP, UDP, SMS
- Wide operating temperature: -40 to 75°C (-40 to 167°F)

I/O Channels Available on ioLogik 2500 Models

Model Name	Digital Inputs	DI/DO (DIO) Configurable	Analog Inputs
ioLogik 2512	8	8	-
ioLogik 2542	-	12	4

Communication Interface

Model Name	Communication Interface
ioLogik 2512	Serial / Ethernet
ioLogik 2542	Serial / Ethernet
ioLogik 2512-GPRS	Serial / Ethernet / GPRS (2G)
ioLogik 2542-GPRS	Serial / Ethernet / GPRS (2G)
ioLogik 2512-HSPA	Serial / Ethernet / GPRS (2G) /HSPA (3G)
ioLogik 2542-HSPA	Serial / Ethernet / GPRS (2G) /HSPA (3G)
ioLogik 2512-WL1	Serial / Ethernet / Wireless LAN
ioLogik 2542-WL1	Serial / Ethernet / Wireless LAN

ioLogik 2500 Specifications



NOTE

The latest specifications for Moxa's products can be found at <https://www.moxa.com>.

2. Installation


In this chapter, we provide instructions on how to install the ioLogik 2500 I/O server to connect to the network and serial devices.

Hardware Installation


Installing the ioLogik 2500 on a DIN Rail

The DIN-rail attachment plate should already be fixed to the back panel of your ioLogik 2500. If you need to reattach the plate, be sure the spring-loaded bracket is oriented towards the bottom, as shown in the figures below.


Step 1: If the spring-loaded bracket is locked in place, push the recessed button to release it. Once released, you should feel some resistance from the spring as you slide the bracket up and down a few millimeters in each direction.



Step 2: Insert the top of the rail into the upper lip of the attachment plate's slot.




Step 3: The attachment unit should now snap into place along the rail, as shown below.



Removing the ioLogik 2500 from a DIN Rail

To remove the ioLogik 2500 from a DIN rail, use a screwdriver to pull down the spring-loaded bracket until it locks in place. Next, rotate the bottom of the ioLogik 2500 upwards until you can remove it from the DIN rail.



WARNING


This equipment is intended to be used in Restricted Access Locations. External metal parts will be hot! Maintenance personnel should wear protective gear before touching the outside surface.



Powering on the ioLogik 2500

The ioLogik 2500 can receive power from a 12 to 48 VDC power source. Input power is applied to the positive (V+) and negative (V-) terminals on the connector.

After connecting the ioLogik 2500 to the power supply, it will take 30 to 60 seconds for the operating system to boot up. The green Ready LED will illuminate continuously until the operating system is ready.



Grounding the Unit

The ioLogik 2500 is equipped with a ground connector labeled .




ATTENTION

Be sure to note the maximum possible current for each power wire and common wire. Observe all electrical codes dictating the maximum current allowable for each wire size. If currents exceed the maximum rating the wires will overheat, and may cause serious damage to the equipment. For safety reasons, wires connecting the power supply should be at least 2 mm in diameter (e.g., 12 gauge).

Installing a microSD Card and SIM Cards (cellular models only)

The ioLogik 2500 supports a single microSD card and two SIM cards (cellular models only). The card slots are located inside the ioLogik 2500, as shown here. The card slot is hidden beneath a cover plate attached by a screw that must first be removed before the slot can be accessed. After removing the screw holding the cover plate in place you can insert or remove the microSD/SIM cards. Be sure to refasten the cover plate when you are done.




I/O Terminal Pinouts

ioLogik 2512 (Top to Bottom)			ioLogik 2542 (Top to Bottom)		
		GND	COM0	1	
0		DI0	DI1	3	
2		DI2	DI3	5	
4		DI4	DI5	7	
6		DI6	DI7		
		GND	COM1		
8		DIO0	DIO1	9	
10		DIO2	DIO3	11	
12		DIO4	DIO5	13	
14		DIO6	DIO7	15	

0	AI0+	AI1+	1
	AI0-	AI1-	
2	AI2+	AI3+	3
	AI2-	AI3-	
	GND	COM0	
4	DIO0	DIO1	5
6	DIO2	DIO3	7
	GND	COM1	
10	DIO6	DIO7	11
12	DIO8	DIO9	13
14	DIO10	DIO11	15

I/O Wiring Diagrams



I/O Wiring

Follow the wiring guide for the I/O channels:

Item	Suggestion
Wire range	16 to 26 AWG
Screw Torque	3 lb-inch


DI Channel

There are two categories of DI contact: Dry Contact and Wet Contact. Follow the wiring diagram for the particular component you are using.


A Dry Contact is a contact that works without a power source: buttons, switches, etc.

A Wet Contact is a contact that requires a power source to work: proximity sensors, motion sensors, etc. Check the sensor type (NPN, PNP) and follow the corresponding wiring shown below.


DI Dry Contact



DI Wet Contact (NPN)




DI Wet Contact (PNP)




DO Channel (Sink Type)

The DIO channels of this series can be used as DI channels or DO channels. The wiring diagram for DO channels, which are sink type, is shown below:



AI Channel



LED Indicators

Type	Color	Description
Power (PWR)	Green	System power is ON
	Off	System power is OFF
Ready (RDY)	Green	System is ready
	Red	System error
	Green (blinking once per sec.)	Locating device
	Red (blinking once per sec.)	Expansion Runtime Error
	Green/Red (blinking once per 0.5 sec.)	Safe Mode
	Off	System is not ready
Ethernet Port (L1/L2/L3/L4)	Green	Ethernet connection enabled at 100 Mbps
	Amber	Ethernet connection enabled at 10 Mbps
	Blinking	Data is being transmitted
	Off	Disconnected
Serial Port (P1/P2)	Green	Tx
	Amber	Rx
	Blinking	Data is being transmitted
	Off	Disconnected
SD (Micro SD)	Green	SD card inserted
	Off	SD card not inserted
I/O Channel Status* (0 to 15)	Green	Channel ON or Counter/Pulse signal
	Off	Channel OFF or No Counter/Pulse signal
W.Link**	Green	Wireless connection established
	Off	Off
Signal Status**	Off	No signal, or No SIM card
	1 LED	Weak or insufficient (SMS only)
	2 LEDs	Average (good for cellular connections)
	3 LEDs	Excellent signal

*Use the rotary switch to select which module's I/O channel status is displayed.

- 0 = ioLogik 2500
- 1 to 8 = E1200 expansion
- 9 to F = Reserved


**Wireless models only

Daisy-Chaining for I/O Expansion

Up to 8 ioLogik E1200 devices can be connected in a daisy chain configuration to the ioLogik 2500 via the L1/Slave port on the ioLogik 2500. An IOxpress configuration scheme is called a project. If the IOxpress project includes expansion devices, the ioLogik 2500 will automatically start running in expansion mode.

If the ioLogik 2500 is running, you can replace one of the expansion units without powering down the ioLogik 2500. Take the following steps to replace an expansion unit:


1. Power-off the expansion unit.
2. Replace the unit with another expansion unit of the same model.
3. Access the DIP switch beneath the cover plate (as shown below).
4. Move the DIP switch from the down position to the up position to trigger the ioLogik 2500 to refresh its connection with the expansion units. If the DIP switch is already in the up position, move it down and then back up again.
5. The expansion unit will start running.



NOTE


Expansion units must be replaced with the same model of expansion unit. If you would like to use a different expansion unit model, you must first change the relevant IOxpress settings.

The following figure illustrates a simple daisy-chain of I/O modules using the ioLogik 2500 for wireless connectivity.



When daisy-chaining an array of devices, the first device in the chain (after the ioLogik 2500) must be connected to the L1 Slave port on the top of the ioLogik 2500 (outlined in red in the diagram).

When a network failure occurs between the ioLogik 2500 and expansion I/O units, the ioLogik 2500's auto-recovery mechanism will reestablish a connection once the network is back up and running.






ATTENTION

When using the ioLogik 2500 as the head of an array of ioLogik E1200 modules, make sure that:

1. You connect the first E1200 expansion module in the array to the ioLogik 2500's L1 Slave port.
2. A maximum of 8 ioLogik E1200 devices are connected in a single array.
3. You only use ioLogik E1200 devices in the array. Other devices cannot be used as part of the array.

Reset to Factory Defaults

If you need to reset the ioLogik 2500 to factory defaults, press and hold the reset button (located under the cover-plate, as shown in the diagram) for more than 5 seconds.



WARNING

Resetting your device to factory defaults will result in the loss of all configuration settings and any Click&Go Plus logic settings that have already been configured.

Network Installation

Ethernet Communication

Connections to the LAN port are made through an RJ45 connector on the ioLogik 2500 device. The wiring and pin connections for these connectors are described in separate sections below.



ATTENTION

The maximum cable length of a 10/100BaseT connection is 100 m (350 feet), but the actual limit could be shorter depending on the amount of electrical noise in the environment. To minimize the amount of noise, Ethernet cables should not run parallel to power cables or other cables that generate electrical noise.

TCP/IP Settings

The following table shows the TCP/IP parameters supported by the LAN port. The ioLogik 2500 will revert to these default values whenever it is reset to factory defaults.

LAN Port	
Parameter	Supported Values
IP Address	Default: 192.168.127.253
Subnet Mask	Default: 255.255.0.0
Gateway	Default: 0.0.0.0

IP Address

The ioLogik 2500's IP address.

Subnet Mask

Determines which subnet the device is connected to.

Gateway


The gateway IP address, which determines how the controller communicates with devices outside its subnet.

The IP address, subnet mask, and gateway are static; contact your network administrator to obtain these addresses for the ioLogik 2500 device.

Serial Communication

The ioLogik 2500 is equipped with two 3-in-1 software-selectable RS-232/422/485 serial ports, making it more convenient to connect serial devices.

If required, the RJ45 to 8-pin male DB9 converter cables can be used to connect to serial devices.




NOTE

The ioLogik 2500 is shipped with 2 RJ45 to DB9 connection cables. If you need additional cables, contact your Moxa sales representative.


The model name of the connection cable is CBL-RJ45M9-150.



RJ45 to DB9 Connection Cable



RJ45 Connector Pinouts



DB9M Connector Pinouts

DB9M Pin	RS-232	RS-422	RS-485	RJ45 Pin
1	DCD	RXD-	DATA-	6
2	RXD	RXD+	DATA+	5
3	TXD	TXD-	-	4
4	DTR	-	-	8
5	GND	GND	GND	3
6	DSR	-	-	1
7	RTS	TXD+	-	2
8	CTS	-	-	7

Software Installation—IOxpress Utility

The ioLogik 2500 can be remotely managed and configured over an Ethernet with Moxa's **IOxpress** utility. IOxpress is a Windows utility provided for the configuration and management of the ioLogik 2500. IOxpress can be used to remotely monitor and configure devices from any location on the network. The IOxpress graphical user interface provides easy access to all status information and configuration settings, and can also be used to configure Click&Go Plus rules and handle front-end events.

System Requirements

Hardware Requirements	
CPU	Intel Pentium 4 CPU or higher
RAM	Min. 512 MB, 1024 MB is recommended
Network Interface	10/100 Ethernet

Software Requirements	
Operating System	Microsoft Windows 2000, XP or later

Installing IOxpress

The software can be downloaded from Moxa's website. To do this, first click on the following link to access the website's search utility:

<http://www.moxa.com/support/search.aspx?type=soft>

When the web page opens, enter the model name of your product in the search box. Click the model name to navigate to the product page, and then click on **Utilities** (in the middle of the page), located in the box titled **Software**.

Download and unzip the file, and then run **SETUP.EXE** from that location.

The installation program will guide you through the installation process and install the software. After the installation is finished, run the software from the Windows Start menu.



NOTE

Additional information on using IOxpress can be found in Chapter 3: The IOxpress Utility.

3. The IOxpress Utility


In this chapter, we introduce Moxa's IOxpress Utility. The ioLogik 2500 can be managed and configured over an Ethernet using the IOxpress graphical user interface, which provides easy access to all status information and settings. IOxpress can also be used to configure Click&Go Plus rules to handle front-end events.

Application Interface

Main Screen

The following figure shows the main screen of the IOxpress utility. There are four main areas:

- **Menu Bar**
- **Quick Launch Bar**
- **Configuration Console**
- **Log Messages**



Menu Bar

There are five tabs on the menu bar:

- **Project:** For managing projects
- **Device:** For accessing functions to manage online devices
- **Configuration:** For performing configurations offline
- **Options:** Network interface and options
- **Help:** Version information



NOTE


If the host computer has multiple interfaces, be sure to select the correct network interface before searching for online devices. If you select the incorrect interface or do not enable an interface, the search action will not find any devices. The interface settings can be found in the menu bar Options > Network Interfaces.

Using IOxpress

IOxpress supports two configuration options: Configuration Library and Device Library. Offline configuration is usually completed first in the Configuration Library, and then the configurations are uploaded over the network to online devices.

Configuration Flowchart

The following flowchart gives an overview of the IOxpress configuration process. Once offline configuration is completed, you can start online configuration.



Configuration Library

The operator uses IOxpress to store configuration options offline in **IOxpress Projects**. The configuration settings are stored on the user's computer.

See Chapter 4 for a detailed explanation.

Device Library

The operator uses IOxpress to export the configuration to devices on the network. That is, settings that were configured offline are exported over the network to online devices. This can be done either in batch mode, or on a case-by-case basis.

IOxpress can also be used to access online devices directly to check I/O status, upgrade firmware, export configurations, and restart devices.

See Chapter 5 for a detailed explanation.

4. Configuration Library

With Configuration Library, the operator uses IOxpress to store configuration options offline in **IOxpress Projects**. The configuration settings are stored on the user's computer.

Introduction

With Configuration Library, the operator uses IOxpress to store configuration options offline in **IOxpress Projects**. The configuration settings are stored on the user's computer.

Saving Configurations as a Project

IOxpress configuration schemes are called **Projects** (saved as *.prj files).


The first step to using IOxpress is to create a project for automating your device configuration processes. This can be done offline, after which the project can be exported to other devices over the network during the online configuration phase (discussed in Chapter 5: Device Library).

Projects are automatically saved in the following folder:

C:\Users\Public\Documents\Moxa\IOxpress\Database

The first time you use offline configuration, create a new project by clicking **New** from the dropdown menu under the **Project** tab.

Click **Configuration Library** and then select **Configuration** from the toolbar. You may click on either **Add (Add Configuration... or **Load from File...**** to add a configuration to the new project.




Adding an ioLogik 2500 Device to a Project

The ioLogik 2500 can be used as the head of a cascaded array of ioLogik E1200 modules, with Click&Go Plus logic used to extend communication capability to the all of the expansion units.

Adding E1200 I/O Expansion Modules to a Project

Up to 8 ioLogik E1200 series devices can be connected to the ioLogik 2500 in a daisy-chain configuration.

Right click on the ioLogik 2500 device you have just added, and then select **Add (Add Configuration....**. After adding an E1200, the settings for the added device can be found in the **I/O settings, Tag selection,** and **data logging – profile** areas. The expansion status (0: disconnect; 1: Good) can be monitored via Modbus, AOPC tag, SNMP, and RESTful API.



ATTENTION

If the IOxpress project includes expansion devices, the L1/slave port will automatically run in expansion mode.




ATTENTION

The IP address of the ioLogik 2500 should not be the same as its E1200 expansion units.



NOTE


The following ioLogik E1200 models can be used for ioLogik 2500 I/O arrays:





NOTE


The order of each model is fixed. If you would like to change a device in an E1200 array, make sure that the order of the expansion modules is the same as in the Expansion Configuration list you just modified. An example is shown below:



Duplicate Device Configuration for Mass Deployment

Use the **Duplicate...** function to quickly duplicate a configuration. First use Duplicate is to save your first configuration as a template, and then use the duplicate function to duplicate the configuration template to devices that have a different name, serial number, and IP address.

To do this, right click on a configuration template and select **Duplicate...** from the dropdown list.




Setting Up a Device

After you have created the project, you can start to configure each device in the project. The configuration window has four tabs:

- **Settings**
- **Click&Go Plus**
- **Click&Go Plus Simulator**
- **Peer-to-Peer**

Settings Tab

The **Settings** panel includes basic settings used to set up devices.



System

Click **System** to configure the following items:

Device Name

During offline configuration, the device name will appear in the list of ioLogik 2500 units. During online configuration, the device name will appear in the mass deployment list. IOexpress supports long device names up to 30 characters.

Time Settings

The ioLogik 2500 will synchronize its time with the time server indicated in the Time Server box. During online configuration, you can sync the PC's time with the ioLogik 2500's time.

Daylight Saving Time

Select the **Enable Daylight Saving Time** checkbox if your region supports daylight saving time, and then configure the Offset Time, Start Date, and End Date.

Device Name	Server 01												
Time Zone	(GMT) Greenwich Mean Time: Dublin, Edinburgh, Lisbon, L												
Time Server	pool.ntp.org												
Time Server Sync Interval	1440												
<input type="checkbox"/> Enable Daylight Saving Time <table border="1" style="margin-top: 10px;"> <tr> <td>Start Date</td> <td>Offset Time</td> <td>1.0 Hour</td> </tr> <tr> <td>Month: Mar</td> <td>Week: Last</td> <td>Day: Sun</td> <td>Hour: 02</td> </tr> <tr> <td>End Date</td> <td>Month: Oct</td> <td>Week: 2nd</td> <td>Day: Sun</td> <td>Hour: 02</td> </tr> </table>		Start Date	Offset Time	1.0 Hour	Month: Mar	Week: Last	Day: Sun	Hour: 02	End Date	Month: Oct	Week: 2nd	Day: Sun	Hour: 02
Start Date	Offset Time	1.0 Hour											
Month: Mar	Week: Last	Day: Sun	Hour: 02										
End Date	Month: Oct	Week: 2nd	Day: Sun	Hour: 02									

Security

Configure the security settings to increase the security level of the device. Be sure to change the default username/password the first time you configure this device, and then change it regularly thereafter.

User Settings

Each ioLogik 2500 is limited to precisely three users. Only the **Username** and **Password** of each user can be modified. The **No.**, **Type**, and **Permission Level** items cannot be changed. Use the Enable check box (default: disable) to enable/disable Operator and User.

User Settings			
No.	Type	Username	Permission Level
0	Administrator	admin	Full Control
1	Operator	operator	I/O Control
2	User	user	Read Only

Enable Administrator
 Username: admin
 New Password: (Length: 4 to 16; characters: A to Z, a to z, 0 to 9, Symbols, at least one number and one symbol)
 Confirm Password:

Modify

Note: Use original username and password when updating the configuration with updated user settings.

The factory defaults and access rights of the three user types are described below:

User Type	Factory Default	Access Right
Administrator	admin	Full control, including the ability to configure the device
Operator	operator	Can control I/O status through the web console
User	user	Can check I/O status through the web console

The characteristics of the username and password are described below:

Username:

Length: 1 to 30 characters
Acceptable characters: A to Z, a to z, 0 to 9, symbols; spaces are not allowed
Factory defaults: (see table above)

Password:

Length: 4 to 16 characters
Acceptable characters: A to Z, a to z, 0 to 9, Symbols, at least one number and one symbol
Factory default: moxa



NOTE

Since the configuration is being done offline, the results are stored in your computer, and not in the ioLogik device. Therefore, when updating this configuration to the ioLogik device, you will need to log in with the previous password.



ATTENTION

To guard against cyber attacks, **the password fields require at least one number and one symbol when updating the password.** Be sure to change the default password of each username before you start using your ioLogik devices, and then change the passwords at regular intervals.

Service Setting

Configure the service settings to enable/disable different services to prevent unintended access. The Default Configuration enables Web Server, Auto Search, and IOxpress Service. Enable other services (e.g., Modbus/TCP Slave) if additional services are required.

No.	Service	TCP/UDP	Port
<input checked="" type="checkbox"/>	0 Web Server	TCP	80
<input type="checkbox"/>	1 CGI Server	TCP	80
<input type="checkbox"/>	2 RESTful API	TCP	80
<input type="checkbox"/>	3 HTTPS	TCP	443
<input type="checkbox"/>	4 SNMP Agent	UDP	161
<input type="checkbox"/>	5 Modbus/TCP Slave	TCP	502
<input checked="" type="checkbox"/>	6 Auto Search	UDP	4800
<input checked="" type="checkbox"/>	7 IOxpress	TCP	10124
<input type="checkbox"/>	8 AOPC	TCP	9500/9900
<input type="checkbox"/>	9 Remote Action Server	TCP	9010
<input type="checkbox"/>	10 FTP Server	TCP	21
<input type="checkbox"/>	11 Peer to Peer Server	TCP	9300

Note: If all services are disabled, this device will no longer be accessible, and you will need to load the factory default configuration to access the device.



NOTE

If all services are disabled, this device will no longer be accessible, and you will need to load the factory default configuration to access the device.



NOTE

MX-AOPC UA Server Service runs through the PC's AOPC data communication ports 9500/9900.

User Account Settings

The user account settings include the following parameters.

Idle Timeout	<input type="text" value="5"/> min(s) (0 to 1440; default = 5)
Retry Failure Threshold	<input type="text" value="5"/> time(s) (1 to 10; default = 5)
Lockout Time	<input type="text" value="5"/> min(s) (1 to 60; default = 5)
Access Log	When the log is full (1000 records max.) <input checked="" type="radio"/> Overwrite the oldest <input type="radio"/> Stop creating new logs
Login Failure Message	<input type="text" value="Login failed. Check the username and password and try again."/> (200 characters max.)
System Use Notification	<input type="text"/> (200 characters max.)

- Idle Timeout: The system will log out idled users automatically when the idle timeout period is surpassed.
- Retry Failure Threshold: Users will be locked out after this many unsuccessful logins.
- Lockout Time: The system will be locked for this period of time when the retry failure threshold is surpassed.
- Login Failure Message: The system message that pops up when after an unsuccessful login.
- System Use Notification: The system message that will be displayed on the login page located below the username and password field.

Access Control

Use IP Address / Netmask combinations to control which devices can use the Modbus/TCP protocol to access your ioLogik device.

Only allow below IP address to access Modbus address

No.	IP Address	Netmask
0	192.168.127.50	255.255.255.0
1	0.0.0.0	255.255.255.0
2	0.0.0.0	255.255.255.0
3	0.0.0.0	255.255.255.0
4	0.0.0.0	255.255.255.0
5	0.0.0.0	255.255.255.0
6	0.0.0.0	255.255.255.0
7	0.0.0.0	255.255.255.0
8	0.0.0.0	255.255.255.0
9	0.0.0.0	255.255.255.0

Network

There are three sub-pages under **Network: General, LAN, Cellular** (applies to the ioLogik 2500-GPRS/HSPA only), and **Wi-Fi** (applies to the ioLogik 2500-WL1 only).

General

There are two columns under General: **Select Network Interface** and **General Settings**.

Select Network Interface

Select Network Interface is only available for the ioLogik 2500-GPRS/HSPA models. See **Chapter 4: Cellular Network Setup and Configuration** for details.

General Settings

General Settings

<input checked="" type="checkbox"/> Enable Web Console
<input checked="" type="checkbox"/> Enable Server Socket Idle Connection Timeout (sec(s)) <input type="text" value="60"/>
Private IP for the First Expansion Module <input type="text" value="192 . 168 . 120 . 1"/>

Enable Web Console

Use this checkbox to enable or disable the web console. When enabled, the ioLogik can be configured from a web browser. If not enabled, you will not be able to open the web console.

Enable Server Socket Idle Connection Timeout



Server Socket Idle Connection Timeout is designed to avoid TCP connection failures when the network host is unable to respond due to a hardware failure or network problem.

If **Server Socket Idle Connection Timeout** is enabled: When the server's connection to the ioLogik 2500 exceeds the specified time period the device will automatically release its TCP connection to the server to free up the port for the next connection.

If **Server Socket Idle Connection Timeout** is not enabled: If the network host is unable to respond due to a hardware failure or network problem, the ioLogik will continue to wait for a response from the host, causing the TCP port to be occupied indefinitely by the host.

Private IP for the First Expansion Module

An array of up to 8 modules can be connected to the ioLogik 2500. Private IP for First Expansion Module assigns an IP to the first E1200 module. The IPs for subsequent modules in the chain will be automatically assigned consecutively. For example, if the IP of the first E1200 device is set to 192.168.120.1, the IP of the second E1200 will be 192.168.120.2, the third IP will be 192.168.120.3, and so on.



LAN

IP Settings

You can set up a static or dynamic IP address for the ioLogik, as well as the subnet mask and gateway address.

Use this field to specify the IP addresses of one or two DNS servers. DNS servers can be used to find available e-mail addresses when setting up Click&Go Plus rules.

IP Setting	
IP Configuration	Static IP
IP Address	192 . 168 . 125 . 1
Netmask	255 . 255 . 0 . 0
Gateway	• • • •
DNS1	• • • •
DNS2	• • • •



NOTE

The ioLogik 2500-WL1 only supports static IP addresses.

Cellular (ioLogik 2500-GPRS/HSPA only)

Cellular is only available for the ioLogik 2500-GPRS/HSPA models. See **Chapter 4: Cellular Network Setup and Configuration** for details.

Wi-Fi (ioLogik 2500-WL1 Only)

Wi-Fi is only available for the ioLogik 2500-WL1 models. See **Chapter 5: Wireless LAN Network Setup and Configuration** for details.

I/O


In the I/O section, you can configure I/O settings for ioLogik 2500 devices. Items that can be modified will be shown in **black**. Items that cannot be modified will be shown in **light gray**. Because revising channel type and name also changes each I/O setting, we recommend configuring the I/O Mode Settings first.

Detail Setting I/O Mode Setting				
<input type="checkbox"/> Enable Communication Watchdog for Safe Mode		30	sec	<input type="checkbox"/> Enable Auto Clear Safe Mode
Slot Number	Channel No	Channel Type	Channel Mode	Name
[Slot 00 Model: 2542 (-T)]	0	AI	0-10V	AI-00
[Slot 00 Model: 2542 (-T)]	1	AI	0-10V	AI-01
[Slot 00 Model: 2542 (-T)]	2	AI	0-10V	AI-02
[Slot 00 Model: 2542 (-T)]	3	AI	0-10V	AI-03
[Slot 00 Model: 2542 (-T)]	4	DIO	DI	DIO-00
[Slot 00 Model: 2542 (-T)]	5	DIO	DI	DIO-01
[Slot 00 Model: 2542 (-T)]	6	DIO	DI	DIO-02
[Slot 00 Model: 2542 (-T)]	7	DIO	DI	DIO-03
[Slot 00 Model: 2542 (-T)]	8	DIO	DI	DIO-04
[Slot 00 Model: 2542 (-T)]	9	DIO	DI	DIO-05
[Slot 00 Model: 2542 (-T)]	10	DIO	DI	DIO-06
[Slot 00 Model: 2542 (-T)]	11	DIO	DI	DIO-07
[Slot 00 Model: 2542 (-T)]	12	DIO	DI	DIO-08
[Slot 00 Model: 2542 (-T)]	13	DIO	DI	DIO-09
[Slot 00 Model: 2542 (-T)]	14	DIO	DI	DIO-10
[Slot 00 Model: 2542 (-T)]	15	DIO	DI	DIO-11
[Slot 00 Model: 2542 (-T)]	16	Virtual Channel	Disable	Virtual Channel-00
[Slot 00 Model: 2542 (-T)]	17	Virtual Channel	Disable	Virtual Channel-01
[Slot 00 Model: 2542 (-T)]	18	Virtual Channel	Disable	Virtual Channel-02
[Slot 00 Model: 2542 (-T)]	19	Virtual Channel	Disable	Virtual Channel-03
[Slot 00 Model: 2542 (-T)]	20	Virtual Channel	Disable	Virtual Channel-04
[Slot 00 Model: 2542 (-T)]	21	Virtual Channel	Disable	Virtual Channel-05
[Slot 00 Model: 2542 (-T)]	22	Virtual Channel	Disable	Virtual Channel-06
[Slot 00 Model: 2542 (-T)]	23	Virtual Channel	Disable	Virtual Channel-07
[Slot 00 Model: 2542 (-T)]	24	Virtual Channel	Disable	Virtual Channel-08
[Slot 00 Model: 2542 (-T)]	25	Virtual Channel	Disable	Virtual Channel-09

Setting	Functions	
IO Mode Setting	Channel Mode Name	
DI Setting	Filter	
Counter Setting	Filter Initial Value Trigger Mode Power Off Storage Power On Value Power On Status	Scaling Enable Scaling Slope Scaling Offset Scaling Interval
DO Setting	Enable Communication Watchdog for Safe Mode Enable Auto Clear Safe Mode	Power On Status Power On Delay Safe Mode Status
Pulse Setting	On Width Off Width Count	Power On Status Power On Delay Safe Mode Status
AI Setting	Channel Mode Burnout Value Scaling Slope	Scaling Offset Scaling Unit
Virtual Channel Setting	Enable Slot No. Channel No.	Function Interval (min) Sampling Time (min)

Select Module

Select the module that you would like to configure. You may select **All** modules, in which case information on all I/O channels in the project will be displayed.



IO Mode Setting

- **Channel Mode**

DIO channels can be set to one of four modes: **DI**, **Event Counter**, **DO**, or **Pulse output**. AI channels can be set to one of five modes: **±10 V**, **0 to 10 V**, **0 to 20 mA**, **4 to 20 mA**, or **4 to 20 mA (Burnout)**. AO channels can be set to one of two modes: **0 to 10 V** and **4 to 20 mA**.



NOTE

Since the ioLogik 2500 does not have AO channels, the AO setting will only show up when the project contains E1200 AO modules, such as the E1241.

- **Name**

The name will be attached to the AOPC tag to help users identify channel information in MX-AOPC.

DI Setting

Filter: Software filtering is used to avoid switch bounces. The filter is configurable in multiples of 100 μ s and accepts values between 1 and 65535.

Detail Setting **DI Setting**

Enable Communication Watchdog for Safe Mode sec Enable Auto Clear Safe Mode

Slot Number	Channel No	Filter	Filter Unit
[Slot 00 Model: 2542 (-T)]	4	1	100 μ s
[Slot 00 Model: 2542 (-T)]	5	1	100 μ s
[Slot 00 Model: 2542 (-T)]	6	1	100 μ s
[Slot 00 Model: 2542 (-T)]	7	1	100 μ s
[Slot 00 Model: 2542 (-T)]	8	1	100 μ s
[Slot 00 Model: 2542 (-T)]	9	1	100 μ s
[Slot 00 Model: 2542 (-T)]	10	1	100 μ s
[Slot 00 Model: 2542 (-T)]	11	1	100 μ s
[Slot 00 Model: 2542 (-T)]	12	1	100 μ s
[Slot 00 Model: 2542 (-T)]	13	1	100 μ s
[Slot 00 Model: 2542 (-T)]	14	1	100 μ s
[Slot 00 Model: 2542 (-T)]	15	1	100 μ s

Counter Setting

Counter refers to an **Event Counter** channel. Counts are stored internally.

Select Type **Counter Settings**

Enable Communication Watchdog for Safe Mode sec(s) Enable Auto Clear Safe Mode

Slot No.	Channel No.	Name	Filter	Filter Unit	Initial Value	Trigger Mode	Power On Status	Power Off Storage	Power On Va...	Scaling Enable
[Slot 00 Model: 2512]	0	DI-00	1	100 μ s	0	Rising edge	Stop	Discard	0	Disabled
[Slot 00 Model: 2512]	1	DI-01	1	100 μ s	0	Rising edge	Stop	Discard	0	Disabled
[Slot 00 Model: 2512]	2	DI-02	1	100 μ s	0	Rising edge	Stop	Discard	0	Disabled
[Slot 00 Model: 2512]	3	DI-03	1	100 μ s	0	Rising edge	Stop	Discard	0	Disabled

- Filter**

Software filtering is used to avoid switch bounces. The filter is configurable in multiples of 100 μ s and accepts values between 1 and 65535.

- Initial Value**

The initial value is the start value in counter mode.

- Trigger Mode**

In **Trigger mode**, the channel accepts limit or proximity switches and counts events according to the ON/OFF status. When **Rising edge** is selected, the counter value increases when the attached switch is pushed. When **Falling edge** is selected, the counter value increases when the switch is released. When **Both** is selected, the counter value increases when the attached switch is pushed or released.

- Power On Status**

To enable the counter to resume counting immediately upon powering up, enable the **Power On Status**.

Stop: The counter starts logging signals only after configured to do so by a Modbus or a Click&Go Plus command.

Start: Counting begins automatically whenever the ioLogik is powered on.

- Scaling Enable / Scaling Slope / Scaling Offset / Scaling Interval (sec)**

Set the **Slope & Offset** to convert the Counter value to a new value. The scaled value = (original value * Scaling Slope) + Scaling Offset.

DO Setting

Detail Setting **DO Setting**

Enable Communication Watchdog for Safe Mode sec Enable Auto Clear Safe Mode

Slot Number	Channel No	Power On Status	Power On Delay (s)	Safe Mode Status
[Slot 00 Model: 2542 (-T)]	8	Off	0	Off
[Slot 00 Model: 2542 (-T)]	9	Off	0	Off
[Slot 00 Model: 2542 (-T)]	10	Off	0	Off
[Slot 00 Model: 2542 (-T)]	11	Off	0	Off

- Enable Communication Watchdog for Safe Mode**

When the watchdog is enabled, any disconnection from the network will activate a safe state. In the safe mode, DO channels can be configured to turn on, turn off, or commence pulse output during the safe state. If the watchdog is not enabled, then DO channel status will remain unchanged during a network disconnection.

To configure a DO for safe mode, set the corresponding value in the **Safe Mode Status** column to ON.

- Enable Auto Clear Safe Mode**

When detecting the reconnection of Ethernet signals, the device will auto clear the safe mode status.

- Power On Status**

When the device is powered on, the status of each DO channel is set to **OFF** by default. This status can be modified to **ON**.

- Power On Delay**

The time delay from tuning DO channels when the power is turned on.

- Safe Mode Status**

Enable Communication Watchdog for Safe Mode allows you to control how DO and pulse output channels act when the network is disconnected.

If the Communication Watchdog is enabled, a network disconnection will activate a safe state. The DO channel can be configured to turn on / turn off during the safe state.


If the Communication Watchdog is not enabled, then the DO channel status will remain unchanged during a network disconnection.

Pulse Setting

Pulse Setting								
Detail Setting		Pulse Setting						
<input type="checkbox"/> Enable Communication Watchdog for Safe Mode		30	sec	<input type="checkbox"/> Enable Auto Clear Safe Mode				
Slot Number	Channel No	On Width	Off Width	Width Unit	Count	Power On Status	Power On Delay (s)	Safe Mode Status
[Slot 00 Model: 2542 (-T)]	12	1	1	100 us	0	Stop	0	Stop
[Slot 00 Model: 2542 (-T)]	13	1	1	100 us	0	Stop	0	Stop
[Slot 00 Model: 2542 (-T)]	14	1	1	100 us	0	Stop	0	Stop
[Slot 00 Model: 2542 (-T)]	15	1	1	100 us	0	Stop	0	Stop

- **On Width / Off Width**

In **Pulse Output mode**, the selected digital output channel will generate a square wave as specified in the pulse mode parameters. The low and high level widths are specified in multiples of 100 μ s, with a maximum setting of 65,535.



- **Count**

You can specify between 1 and 4,294,967,295 pulses or enter "0" for continuous pulse output.

- **Power On Status**

When the device is first powered on, the status of each pulse output channel is set to **OFF** by default.

You can set a pulse output channel to turn **ON** when the ioLogik is powered on, or to commence pulse output.

- **Power On Delay**

The time delay from tuning Pulse channels when the power is turned on.

- **Safe Mode Status**

If the Communication Watchdog is enabled, a network disconnection will activate a safe state. The pulse output channel can be configured to turn on / turn off during the safe state.

AI Setting


AI Setting						
Detail Setting		AI Setting				
<input type="checkbox"/> Enable Communication Watchdog for Safe Mode		30	sec	<input type="checkbox"/> Enable Auto Clear Safe Mode		
Slot Number	Channel No	Channel Mode	Burnout Value	Scaling Slope	Scaling Offset	Scaling Unit
[Slot 00 Model: 2542 (-T)]	0	0-10V	1.000000	0.000000	V	
[Slot 00 Model: 2542 (-T)]	1	0-10V	1.000000	0.000000	V	
[Slot 00 Model: 2542 (-T)]	2	0-10V	1.000000	0.000000	V	
[Slot 00 Model: 2542 (-T)]	3	0-10V	1.000000	0.000000	V	

- **Channel Mode**

The input channels can be set individually to ± 10 V, 0 to 10 V, 0 to 20 mA, 4 to 20 mA, and 4 to 20 mA (Burnout).


- **Burn-out Value**

Burn Out mode indicates when the Current AI has burned out. For example, the 4–20 mA Burn-out mode is defined in the following diagram:



Users can define Burn-out (BO) values (default = 2 mA) for selected ranges. When input values are in the Burn Out range, raw data will register as 0000h to indicate that the analog input has burned out. The definition of raw data is as follows:

Burnout Value (BO)	$0.0 < BO < 4.0$	User defined (default 2 mA)
Burnout State	$0 \leq AI < BO$ mA	Modbus output 0000h
Under Range	$BO \leq AI < 4$ mA	Modbus output raw data
Normal Range	$4 \leq AI \leq 20.00$ mA	Modbus output raw data until FFFEh
Over Range	$XX > 20.00$ mA	Modbus output FFFFh



- **Scaling Slope / Scaling Offset / Scaling Unit**

Enabling the Scaling functions will linearly convert the actual current or voltage value into other user-defined units, such as percentage or ppm (parts per million).

Set the **Slope & Offset** to convert the AI value to a new value. The scaled value = (original value * Scaling Slope) + Scaling Offset.

AO Setting

Detail Setting **AO Setting**

Enable Communication Watchdog for Safe Mode 30 sec Enable Auto Clear Safe Mode

Slot Number	Channel No	Channel Mode	Scaling Slope	Scaling Offset	Scaling Unit	Power On Status	Safe Mode Status
[Slot 02 Model: E1241 (-T)]	0	4-20mA	1.000000	0.000000	mA	4.000000	4.000000
[Slot 02 Model: E1241 (-T)]	1	4-20mA	1.000000	0.000000	mA	4.000000	4.000000
[Slot 02 Model: E1241 (-T)]	2	4-20mA	1.000000	0.000000	mA	4.000000	4.000000
[Slot 02 Model: E1241 (-T)]	3	4-20mA	1.000000	0.000000	mA	4.000000	4.000000

- Channel Mode**

There are two modes for the AO channels: Voltage Mode (V) and Current Mode (mA).

- Scaling Slope / Scaling Offset / Scaling Unit**

Enabling the Scaling functions will linearly convert the actual current or voltage value into other user-defined units, such as percentage or ppm (parts per million).

Set the **Slope & Offset** to convert the AO value to a new value. The scaled value = (original value * Scaling Slope) + Scaling Offset.

- Power On Status**

When the device is first powered on, the status of each AO channel can be modified using the **Power On Status**.

- Safe Mode Status**

Enable Communication Watchdog for Safe Mode allows you to control how an AO channel acts when the network is disconnected.

If the Communication Watchdog is enabled, a network disconnection will activate a safe state. The AO channel can be configured to a defined value during the safe state.



NOTE

Since the ioLogik 2500 does not have AO channels, the AO setting will only show up when the project contains E1200 AO modules (such as the E1241).

Virtual Channel Setting


Detail Setting **Virtual Channel Setting**

Enable Communication Watchdog for Safe Mode 30 sec Enable Auto Clear Safe Mode

Slot Number	Channel No	Enable	Slot No	Channel No	Function	Interval (min.)	Sampling Time (min.)
[Slot 00 Model: 2542 (-T)]	16	Disable	2542 (-T)	None	Maximum	1	
[Slot 00 Model: 2542 (-T)]	17	Disable	2542 (-T)	None	Maximum	1	
[Slot 00 Model: 2542 (-T)]	18	Disable	2542 (-T)	None	Maximum	1	
[Slot 00 Model: 2542 (-T)]	19	Disable	2542 (-T)	None	Maximum	1	
[Slot 00 Model: 2542 (-T)]	20	Disable	2542 (-T)	None	Maximum	1	
[Slot 00 Model: 2542 (-T)]	21	Disable	2542 (-T)	None	Maximum	1	
[Slot 00 Model: 2542 (-T)]	22	Disable	2542 (-T)	None	Maximum	1	
[Slot 00 Model: 2542 (-T)]	23	Disable	2542 (-T)	None	Maximum	1	
[Slot 00 Model: 2542 (-T)]	24	Disable	2542 (-T)	None	Maximum	1	
[Slot 00 Model: 2542 (-T)]	25	Disable	2542 (-T)	None	Maximum	1	

The ioLogik 2500 has 10 internal virtual channels to support front-end statistics functions.

The data source is the real I/O channel, such as AI and DI counters, some of which need to be converted to the appropriate time unit. The operation is illustrated below.




NOTE

For AI/Counter scaling, configure Scaling on the AI or Counter Configuration panel before selecting operations in the virtual channels.

For example, if you want to monitor the daily flow at a point in a pipeline, you can use a pulse output flow meter, where 1 pulse indicates 5 ml. You can set the virtual channel's **scaling function** so that 1 tick of counter input equals 5 ml. Next, set the **Accumulation** flag, and configure the **Time Interval** to 24 hours. This will set up the virtual channel to log the total water flow volume over a period of 24 hours.

- **Status**
Enable/Disable virtual channels.
- **Slot No.**
If you have connected E1200 expansion modules, select the device you would like to configure here.




- **Channel No.**
Virtual channels are required to configure AI or counter channels.

- **Function**

There are six functions: Max, Min, Average, Accumulation, Instantaneous, and Incremental.


- **Maximum:**

The maximum value within Z sec, with sampling done every 10 ms.




- **Minimum:**

The minimum value within Z sec, with sampling done every 10 ms.




- **Average:**

The average value within Z sec, with sampling done every 10 ms.




➤ **Instantaneous:**

The instantaneous value when a sample is taken.




➤ **Incremental:**

The difference (Δ) between two samples.



➤ **Accumulation:**

The sum (Σ) of all sampling values.



- **Interval (min.)**

Set the interval time (Minutes) for Maximum, Minimum, and Average functions.

- **Sampling Time (min.)**

Set the sampling time (Minutes) for Instantaneous and Incremental functions.

AOPC

Moxa MX-AOPC Server is a software package operated as an OPC driver of an HMI or SCADA system. It offers seamless connection from Moxa ioLogik series products to SCADA systems.

Server Connection

You can set the ioLogik 2500 to connect to MX-AOPC UA Server. Each ioLogik 2500 series can connect to two MX-AOPC UA servers. You can also set different modes to send active tags.

The screenshot shows the configuration interface for the MX-AOPC UA Server. At the top, there is a checkbox labeled "Enable connection to AOPC Server with heartbeat interval" with a value of "30 sec(s)". Below this is a section titled "Server Mode" with three radio button options: "Single Server" (selected), "Dual Servers", and "Failover". For "Single Server", the IP address is "0 . 0 . 0 . 0". For "Dual Servers", the IP address for the 2nd server is also "0 . 0 . 0 . 0". The "Port" is set to "9900". Under "Failover", "Retry Times" is set to "3" and "Retry Interval" is set to "3 sec(s)".

Note:

1. The network failure data buffer can store up to 20,000,000 records. You can enable this function on the "Data Logging > Profile" page.
2. The shortest interval for recording tags in the data buffer is 5 seconds.

Enable connection to AOPC Server with heartbeat interval

The **Heartbeat Interval** can be used to determine the connection status between the ioLogik 2500 and MX-AOPC Server, and to ensure that the ioLogik 2500 is connected and alive. If the heartbeat interval is set and the network between the ioLogik 2500 and MX-AOPC Server is down, MX-AOPC Server will detect the stopped heartbeat and the Quality column in the MX-AOPC Server will display BAD to indicate the loss of connectivity.

Server Mode

The ioLogik 2500 can send active tags to one or two MX-AOPC UA servers. You may choose one of three server modes.

1st AOPC Server

IP address of the 1st AOPC server.

2nd AOPC Server

IP address of the 2nd AOPC server.

Single Server

The ioLogik 2500's active tags will be sent to a single AOPC server.

Dual Servers

The ioLogik 2500's active tags will be sent to two AOPC servers.

Fail Over


The ioLogik 2500 will try to connect with the first MX-AOPC Server IP. If it cannot connect, it will automatically connect with the second IP, and when the connection to the second IP fails, it will switch back to the first IP.

Data buffer for network failure

The ioLogik 2500 supports a data buffer function that stores transmitted data on an inserted SD card when the connection between MX-AOPC UA Server and the ioLogik 2500 was down. MX-AOPC UA Logger will automatically retrieve the buffering data after the connection between MX-AOPC UA Server and the ioLogik 2500 is back up and running. The network data buffer can store up to 20,000,000 records. Enable this function under **Data Logging (Profile)**. For details, see the "Data Logging" section of this document; the shortest interval for recording tags is 5 seconds. Refer to the MX-AOPC UA Server and Logger user's manuals for details.

Tag Selection

Use tag selection to select which active tags will be updated to MX-AOPC UA server.



Slot No.	Channel No.	Name	Description	On Change
[Slot 00 Model: 2542-HSPA]	4	DIO-00	Desc	Enabled
[Slot 00 Model: 2542-HSPA]	5	DIO-01	Desc	Enabled
[Slot 00 Model: 2542-HSPA]	6	DIO-02	Desc	Enabled
[Slot 00 Model: 2542-HSPA]	7	DIO-03	Desc	Enabled
[Slot 00 Model: 2542-HSPA]	8	DIO-04	Desc	Enabled
[Slot 00 Model: 2542-HSPA]	9	DIO-05	Desc	Enabled
[Slot 00 Model: 2542-HSPA]	10	DIO-06	Desc	Enabled
[Slot 00 Model: 2542-HSPA]	11	DIO-07	Desc	Enabled
[Slot 00 Model: 2542-HSPA]	12	DIO-08	Desc	Enabled
[Slot 00 Model: 2542-HSPA]	13	DIO-09	Desc	Enabled
[Slot 00 Model: 2542-HSPA]	14	DIO-10	Desc	Enabled
[Slot 00 Model: 2542-HSPA]	15	DIO-11	Desc	Enabled

Select Module

Use the select module function to check the ioLogik 2500 and its IO expansion modules. If you select **All**, all modules will be selected.

I/O Type

Select the type of data you would like to record. Choose from DI, Counter, DO, Pulse, AI, Internal Register, Virtual Channel, Serial Tag, and RSSI (cellular models only).

Select All/Unselect All

You may select all channels, or deselect all channels.

Apply to All

You can apply one parameter to all channels. For example, if you can change **On Change** from **disabled** to **enabled** and then click **Apply to All**, all AI channels will be enabled.

Update Method

- On Change for DI/DO/Pulse/System Tags:** The ioLogik will update the tag value to MX-AOPC UA Server whenever the tag status changes.
- On Change for AI Tag:** If the AI is configured to update on change, the percentage settings represent the percentage of the full analog range. For example, if the AI is configured to 0 to 10 V, "On Change 1%" means the ioLogik will update to the MX-AOPC Server every time there is 0.1 V change.
- Interval for Counter/AI/RTD/TC/IR/FIR/VC/Serial Tags:** The ioLogik will update the tag value to MX-AOPC UA Server when the interval time elapses. The interval time can be configured to between 1 and 65535 seconds; the default is 5 seconds.



NOTE

A shorter interval time may cause a large number of data packets to be generated, resulting in higher data fee if you are using a pay-by-packet connection plan. The ioLogik might also experience higher system loading and unstable performance.

SNMP

The ioLogik supports SNMP (Simple Network Management Protocol) v1, v2c, and v3 to monitor network and I/O devices with SNMP Network Management software. It is useful in building automation and telecom applications. Use these fields to enable SNMP and set the read and write community strings for SNMPv1 and SNMPv2c, or use authentication for SNMPv3.

Enable SNMP

Version	V1 and V2c and V3
Contact	<input type="text"/>
Location	<input type="text"/>
SNMP V1, V2c	
Read Community	<input type="text" value="public"/>
Write Community	<input type="text" value="private"/>
SNMP V3 Read Only	
User Name	<input type="text"/>
Authentication Protocol	DISABLE
Authentication Password	<input type="text"/>
Privacy Protocol	DISABLE
Privacy Password	<input type="text"/>
SNMP V3 Read/Write	
User Name	<input type="text"/>
Authentication Protocol	DISABLE
Authentication Password	<input type="text"/>
Privacy Protocol	DISABLE
Privacy Password	<input type="text"/>

Modbus/TCP Slave

In this section, I/O addresses can be configured for different formats. Select the **Enable Modbus Service** checkbox to enable the Modbus/TCP Slave function of the device. The device supports user-defined Modbus addresses for mapping Modbus data to existing upper level programs; update the start address of each item and to map data to the configured address.

Enable Modbus Service

<input type="checkbox"/>	All	<input type="checkbox"/> Enable host connection timeout	60	sec(s) (1 to 65535)	Restore Default		
No.	Slot No.	Description	Point Type	Read/Write	Start Address (DEC)	Reference Address (DEC)	Total Channels
0	[Slot 00 Mo...]	DI Value	02: INPUT STATUS	Read Only	0	10001	8
1	[Slot 00 Mo...]	DI Counter Value	03: HOLDING REGI...	Read/Write	0	40001	8
2	[Slot 00 Mo...]	DIO Value	01: COIL STATUS	Read/Write	0	00001	8
3	[Slot 00 Mo...]	DIO Counter Value	03: HOLDING REGI...	Read/Write	100	40101	8
4	[Slot 00 Mo...]	DIO Pulse Status	01: COIL STATUS	Read/Write	100	00101	8
5	[Slot 00 Mo...]	Internal Register	03: HOLDING REGI...	Read/Write	500	40501	48
6	[Slot 00 Mo...]	Float Internal Register	03: HOLDING REGI...	Read/Write	1000	41001	48
7	[Slot 00 Mo...]	DI Counter Start/Stop	01: COIL STATUS	Read/Write	1200	01201	8
8	[Slot 00 Mo...]	DIO Counter Start/Stop	01: COIL STATUS	Read/Write	1300	01301	8
9	[Slot 00 Mo...]	P2P Connection Status	02: INPUT STATUS	Read Only	1400	11401	16
10	[Slot 00 Mo...]	Virtual Channel Value	04: INPUT REGISTER	Read Only	1500	31501	10
11	[Slot 00 Mo...]	Reset DI Counter	01: COIL STATUS	Read/Write	1600	01601	8
12	[Slot 00 Mo...]	Reset DIO Counter	01: COIL STATUS	Read/Write	1700	01701	8
13	[Slot 00 Mo...]	Clear Safe Mode	01: COIL STATUS	Read/Write	1800	01801	1

Enable Modbus Service

Enable/Disable the Modbus service setting to turn the Modbus/TCP slave protocol on or off.

Enable host connection timeout

Enable the host connection timeout setting to monitor the Modbus connection status between the Modbus Master and the ioLogik 2500 Modbus service. The connection status can be a condition of a Click&Go Plus rule.

Restore Default

Click the Restore Default button to restore default settings of the Modbus service.

Modbus/TCP Master

The ioLogik 2500 supports a Modbus/TCP Master function that acts as a Modbus/TCP master for monitoring the data from two connected Modbus/TCP slave devices. The collected data can be used by Click&Go Plus or in an upper level system after the data is transmitted via a Modbus, AOPC, SNMP, or RESTful API connection. The data can also be recorded locally using the Data Logging function.

Device

Configure the connected Modbus/TCP slave device settings.

No.	Device Name	IP Address	Port	Delay between Polls
0	ModbusTCPDevice_0	192.168.127.200	502	1000
1	ModbusTCPDevice_1	0.0.0.0	502	1000

Device Settings

Enable Data Collection

Device Name: ModbusTCPDevice_0 (max. length=30; '.' is not allowed)

IP Address: 192 . 168 . 127 . 200

Port: 502

Delay between Polls: 1000 ms (range = 100 to 3600000; default = 1000)

Status Tag: ModbusTcpMasterDeviceStatus_0

Advanced...


Connection Timeouts: 3000 ms Reconnect Delay: 3000 ms

Reconnect Cycles: 3 Cycle Delay: 3 sec(s)

Polling Timeouts: 3000 ms Polling Retries: 3

- **Enable Data Collection:** Check to enable Modbus data collection
- **Device Name:** Name the slave device (e.g., Flow Meter)
- **IP Address:** Fill in the IP address of the slave device
- **Port:** Fill in the Modbus communication port of the slave device (default: 502)
- **Delay between polls:** Set the delay time between polls (default: 502)

Click the **Advanced** button to display the advanced fields for timeout/retry settings. Refer to the connection cycle diagram below for details.



- Connection Timeouts: Modbus initial connection timeout
- Reconnect Delay: Delay time between timeout and start slave device reconnection
- Reconnect Cycles: Set reconnect times for each slave device reconnection cycle
- Cycle Delay: Delay time between each reconnection cycle
- Polling Timeouts: Set timeout to trigger a polling retry for polling command
- Polling Retries: The number of polling retry times for the polling command before proceeding with reconnection

Address

Configure the address settings for monitoring the Modbus/TCP slave device configured in the previous paragraph.

Modbus Point Settings							
No.	Device Name	Device ID	Point Type	Access	Profile Name	Start Address	Length
0	ModbusTCPDevice_0	1	03: Read Holding R...	Read/Write	Profile_0	0	2
<input type="button" value="Add"/> <input type="button" value="Apply"/> <input type="button" value="Delete"/>							

Modbus Point Settings Form:

Device Name	ModbusTCPDevice_0	
Device ID	1	
Point Type	03: Read Holding Registers	Access: Read/Write
Profile Name	Profile_0	(max.length=28; "." is not allowed)
Start Address	0	(0 to 65535)
Register Length	2	(1 to 48)
Start Internal Register	WORD	0
Data Conversion	HiByte & LoByte	

- Device Name: Select which devices will be configured under **Modbus/TCP Master > Device**
- Device ID: Set target slave device ID
- Point Type: Set the corresponding Modbus point type setting
- Profile Name: Name this address setting
- Start Address: Set the start address of the data to be collected
- Length: Set the length of the data to be collected


- Start Internal Register: Set the internal register data type and start number for storing data collected by the ioLogik 2500
- Data Conversion: Select a data conversion option

Register Type	Data Conversion Option
WORD	HiByte & LoByte LoByte & HiByte
DWORD	HiWord & LoWord LoWord & HiWord
FLOAT	HiWord & LoWord LoWord & HiWord

The ioLogik 2500 supports 4 Internal Register types. Each type has 48 registers for storing the collected device data:

- BOOL Internal Register
- WORD Internal Register
- DWORD Internal Register
- FLOAT Internal Register

For example, if you create a setting with Coil Length = 5 bits and Start Internal Register = BOOL 0, then the ioLogik 2500 will store the collected device data in Internal register (BOOL) No. 0 to No. 4.



Use the auto-naming function to append the serial number to the names of the Internal Registers.

- Step 1:** **Start Postfix No.** is the first number that will be appended to the first IR, and **Length** is how many registers you would like to apply the append function to.
- Step 2:** **Select the Internal Register Name column** that will start internal register and set the register name.
- Step 3:** **Click Auto-naming** to automatically name internal registers by appending the serial number.

No.	Name	Initial Value
0	WORD Internal Register-00	0
1	WORD Internal Register-01	0
2	WORD Internal Register-02	0
3	WORD Internal Register-03	0
4	WORD Internal Register-04	0
5	WORD Internal Register-05	0
6	WORD Internal Register-06	0
7	WORD Internal Register-07	0
8	WORD Internal Register-08	0
9	WORD Internal Register-09	0

No.	Name	Initial Value
0	FLOAT Internal Register-00	0.000
1	FLOAT Internal Register-01	0.000
2	FLOAT Internal Register-02	0.000
3	FLOAT Internal Register-03	0.000
4	FLOAT Internal Register-04	0.000
5	FLOAT Internal Register-05	0.000
6	FLOAT Internal Register-06	0.000
7	FLOAT Internal Register-07	0.000
8	FLOAT Internal Register-08	0.000
9	FLOAT Internal Register-09	0.000

No.	Name	Initial Value
0	laser Sensors0	0
1	Laser Sensors1	0
2	Laser Sensors2	0
3	Laser Sensors3	0
4	Laser Sensors4	0
5	BOOL Internal Register-05	0
6	BOOL Internal Register-06	0
7	BOOL Internal Register-07	0
8	BOOL Internal Register-08	0
9	BOOL Internal Register-09	0

Serial Port (Port1/Port2)

The ioLogik 2500 supports two serial ports for connecting to serial devices. For serial wiring instructions, check the section **Installation (Serial Communication)**.

Port Settings

Use port settings to set the serial port's parameters.

Port Settings					
Mode	RS-232	Flow Control	None		
Baudrate	115200	Data Bits	8		
Stop Bits	1	Parity	None		

Mode

Supports RS-232/RS-422/RS-485

Baudrate

Supports 300, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 bps

Stop Bits

Supports 1, 2

Flow Control

Supports None, RTC/CTS, XON/XOFF

Data Bits

Supports 5, 6, 7, 8

Parity

Supports Even, Odd, None

Operation Mode

Each port supports 4 operation modes: Transparent Serial Tunnel (TCP Client), Transparent Serial Tunnel (TCP Server), MODBUS TCP Gateway, and Modbus Serial Tag.

Transparent Serial Tunnel (TCP Client/Server)

Transparent Serial Tunnel mode can create a TCP socket to a remote host program and transparently send and receive data to attached legacy serial devices.



- **Transparent Serial Tunnel (TCP Client)**



- **Remote Address:** The IP address of the remote host program.
- **Remote Port:** The TCP port of the remote host program (1 to 65535; default = 1)

- **Transparent Serial Tunnel (TCP Server)**




- **Listen Port:** The TCP port of the ioLogik for the remote host program to establish a connection (1 to 65535; default = 4001).
- **Idle Timeout:** The idle timeout for the ioLogik to disconnect the TCP connection (1 to 65535 min(s); default = 10).

Modbus TCP Gateway

This function allows users to attach a serial Modbus/RTU meter to the ioLogik 2500's serial port.



- **Modbus TCP Gateway**



- **Serial Response Timeout:** The timeout setting for waiting for a response from a connected serial device (30 to 65535 ms; default = 2500).

Modbus Serial Tag

This function allows users to attach a serial Modbus/RTU meter to the ioLogik 2500's serial port and create the serial tags in the MX-AOPC UA Server so that a SCADA system can access this serial data directly via OPC connections.



Modbus Serial Tag

Operation Mode

No.	Tag Name	Data Type	Data Conversion	Device ID	Start Address	Fn
0	Tag1	Float	LoWord & HiWord	1	2500	0
1	Tag2	Float	HiWord & LoWord	1	2600	0

Name: Tag2
 Data Type: Float
 Device ID: 1
 Function Code: 03: Read Holding Registers
 Data Conversion: HiWord & LoWord
 Start Address: 2600

Add Apply Delete

- **Timeout Setting:** The timeout setting for the ioLogik to wait for a response from a connected serial device when polling Modbus registers (1 to 65535 sec(s); default = 5).
- **Name:** Specify a name for the serial tag.
- **Data Type:** Select the data type assigned to the serial tag (options: Boolean, WORD, DWORD, Float).
- **Device ID:** Set the device id of the connected serial device.
- **Function Code:** Select the function code for ioLogik to poll this Modbus register (options: "01: Read Coil Status," "02: Read Input Status," "03: Read Holding Registers," "04: Read Input Registers.")
- **Data Conversion:** If the data type of the serial tag is WORD, and the function code is 03 or 04, the serial tag can be set to "HiByte & LoByte" or LoByte & HiByte." If the data type of the serial tag is DWORD or Float, and the function code is 03 or 04, the serial tag can be set to "HiWord & LoWord" or LoWord & HiWord."
- **Start Address:** Define the start address of the Modbus register for the ioLogik to poll.
- **Add:** Click the add button after you finish the above settings.
- **Apply:** Click the serial tag you want to modify, change the settings of this serial tag, and then click the apply button to make it effective.
- **Delete:** Click the serial tag you want to delete, and then click delete button to delete this serial tag.



ATTENTION

If the Serial Tunnel setting is used in ioLogik 2500 cellular models, the network should be set to **Cellular Always On** (under: Settings > Network > General > Select Network Interface). Otherwise, the Cellular connection will disconnect and a serial tunnel will not be created.

Data Logging

Install a microSD card in the ioLogik 2500 to use the ioLogik 2500's data logging function. IOxpress will calculate the total amount of external memory required; use an SD card with the appropriate amount of memory.

To use the data buffer function with AOPC, check **Enable data buffer for network failures**. (Note: this function requires 2 GB of external memory.) The following values are available for data logging: **I/O channels**, **Internal registers**, **virtual channels**, and **serial tags**.

Profile

A total of 10 profiles can be created, and multiple/duplicate channels can be included in different profiles.

Step 1: Define this data logging profile's name.

Step 2: Use the Select Tag panel shown below to select channels and then click **Add** to add those channels to a profile.

Step 3: If you made changes to the profile settings, click **Apply** to update the profile settings.

Required external memory size: 3 GB (support microSD up to 32 GB)

Enable data buffer for network failures (requires 2 GB of memory)

Timestamp column: Device local time UTC and time zone

No.	Profile Name	Storage	Max. Records	Records per File	
0	TEST	External	5120000	1000	

Profile Settings

Name

Enable at Power On

Maximum

512

x 10,000 records

Records

1

x 1,000 records (1 to 65; default: 1)

(Note: Maximum records must be at least double the Records per

Select Tag

Select Module

All

Select All

Unselect All

Apply to All

I/O Type

DI

Slot No.	Channel No.	Name	On Change
<input type="checkbox"/> [Slot 00 Model: 2542-GPRS]	4	DIO-00	Enabled
<input type="checkbox"/> [Slot 00 Model: 2542-GPRS]	5	DIO-01	Enabled
<input type="checkbox"/> [Slot 00 Model: 2542-GPRS]	6	DIO-02	Enabled
<input type="checkbox"/> [Slot 00 Model: 2542-GPRS]	7	DIO-03	Enabled
<input type="checkbox"/> [Slot 00 Model: 2542-GPRS]	8	DIO-04	Enabled
<input type="checkbox"/> [Slot 00 Model: 2542-GPRS]	9	DIO-05	Enabled
<input type="checkbox"/> [Slot 00 Model: 2542-GPRS]	10	DIO-06	Enabled
<input type="checkbox"/> [Slot 00 Model: 2542-GPRS]	11	DIO-07	Enabled
<input type="checkbox"/> [Slot 00 Model: 2542-GPRS]	12	DIO-08	Enabled
<input type="checkbox"/> [Slot 00 Model: 2542-GPRS]	13	DIO-09	Enabled

Add

Apply

Delete

Timestamp column

Each piece of logged data has a time stamp. The timestamp can be set to **device local time** or **UTC and time zone**.

Device Local Time

The ioLogik 2500 will log data using the device's local time, which will be stored in a separate column in the log file.

UTC and time zone

The ioLogik 2500 will log the UTC time and time zone, which will be stored in separate columns in the log file.

Profile Settings

The selected data will be logged in a profile. The profile name will be used as the folder name on the microSD card for storing logged data. The profile settings allow you to select the channel you want to log and configure settings (e.g., Enable at power on and profile Size) for each profile.

The profile is saved to a folder based on the profile name. The filename is based on the creation time.

ftp://IP address of device : port/profile name/yyyy/mmddhhxx.csv

- yyyy: year
- mm: month
- dd: date
- hh: hour (24-hour clock)
- xx: sequence number (00 to 99)

Name

The profile name will also be used as the folder name on the microSD card for storing logged data.

Enable at Power On

Enable this function to start data logging at power on. You can also use Click&Go Plus rules to enable/disable the logging features of each profile.

Maximum records

The Maximum records setting puts an upper limit on the amount of data that can be logged. **When the limit is reached, the newest data will overwrite the oldest data.**



NOTE

The total size of the profiles should be less than the size of the microSD card. Otherwise, the data cannot be logged onto the microSD card. 1,000,000 records require about 1 MB of memory space.

Records per File

The Records per File setting sets an upper limit on the number of records allowed per file. When a particular file reaches the maximum number of records, the device will create a new file in the same profile folder and then continue to record data.

Select Tag

For a given profile, you can select which tags you would like to record.

Select Module

You can check ioLogik 2500 and its IO expansion module by using the select module function. If you select **ALL**, all modules will be selected.

I/O Type

You can select the type of the data you would like to record. Types of data that can be recorded include DI, Counter, DO, Pulse, AI, Internal Register, Virtual Channel, Serial Tag.

Select All/Unselect All

You can select all channels or unselect all channels with a single click.

Apply to All

You can apply one parameter to all channels. For example, you can change **On Change** from disable to enable and then click **Apply to All**. The On Change enable setting will be applied to all AI channels.

Log Method

- **On Change for DI/DO/Pulse/System Tags:** The ioLogik will log tag values to the file whenever the tag status changes.
- **On Change for AI Tag:** If the AI is configured to log on change, the percentage settings represent the percentage of the full analog range. For example, if the AI is configured to 0 to 10 V, "On Change 1%" means the ioLogik will log to file every time there is 0.1 V change
- **Interval for Counter/AI/RTD/TC/IR/FIR/VC/Serial Tags:** The ioLogik will log tag values to file when the interval time elapses. The interval time can be configured to between 5 and 86400 seconds; the default is 5 seconds.

FTP

The FTP item defines how to log I/O data to an FTP server. The FTP Service function provides upload service for data log files stored on the MicroSD card.

The image shows the configuration interface for the FTP service. It includes two main sections: 'FTP Client0 Settings' and 'Enable FTP Server'.

FTP Client0 Settings:

- IP (or URL): ftp://
- Port: 21
- Username: (empty)
- Password: (empty)
- Confirm Password: (empty)
- Timeout (ms): 1000

Enable FTP Server:

- Enable FTP Server:
- Username: admin
- Password: (redacted)
- Confirm Password: (redacted)

FTP Client1 Settings:

- IP (or URL): ftp://
- Port: 21
- Username: (empty)
- Password: (empty)
- Confirm Password: (empty)
- Timeout (ms): 1000

FTP Client Settings

The device can act as a client to actively send log files to a predefined FTP server address.

IP (or URL)

The IP address of the FTP server.

Port

The Port number of the FTP server.

Username

The username used to log in to the FTP server.

Password

The password used to log in to the FTP server.

Timeout (ms)

The ioLogik 2500 will disconnect the session when this timeout is reached (100 to 65535 ms; default = 1000).

FTP Server Settings

The device can be an FTP server for FTP clients to retrieve logged data. The logged file is read-only.

The address to access data will be stored in the following address: `ftp://IP address of device : port/profile name/yyyy/mmddhhxx.csv`

- yyyy: year
- mm: month
- dd: date
- hh: hour (24-hour clock)
- xx: sequence number (00 to 99)

Enable FTP server

To enable or disable the FTP server function.

Username

The FTP server's username.

Password

The FTP server's password.



NOTE

Default username: admin


Default password: moxa

Click&Go Plus

Click&Go Plus provides the functional elements that can be used in Click&Go Plus rules, including Timer, SNMP trap, TCP/UDP message, Email, Schedule, Internal Register, Remote Action, and CGI command. You must set all of these elements before you start configuring your Click&Go rules. When a set of rules (known as a rule-set) is defined using Click&Go Plus, the ioLogik can perform local and remote I/O control, report I/O status, and actively send out messages, e-mails, or SNMP traps to a host as soon as the user-defined I/O conditions have been met.


For a detailed introduction on how to use this function, refer to Chapter 2 of the *Click&Go Plus User's Manual*.

Click&Go Plus Tab




Click&Go Plus logic provides an easy way to program your ioLogik 2500 product for smarter I/O functionality over an Ethernet network. For a detailed introduction on how to use Click&Go Plus, refer to Chapter 3 of the *Click&Go Plus User's Manual*.

Click&Go Plus Simulator Tab



When you finish defining your Click&Go Plus rules, you can use the Click & Go plus Simulation tool to test the rules. For a detailed introduction of how to use this function, refer to Chapter 4 of the *Click&Go Plus User's Manual*.

Peer-to-Peer Tab




In some remote automation implementations, the control room and field sensors may be located far apart from each other, often with only a single remote I/O module to collect data from all the sensors.

Peer-to-peer communication has little or no limitation since it replaces cable by integrating multiple I/O signals over a single network cable to transmit input-to-output controls without the aid of PLCs or controllers.

With peer-to-peer communication and support for channel-to-channel mapping, the ioLogik 2500 allows simultaneous multiple target transmissions. In addition, the ioLogik 2500 supports up to 16 channels for transmission over Ethernet (based on an emitter and receiver I/O pair).

Click on **Peer to Peer** in the menu bar to configure basic device settings.



General Settings

Heartbeat (Sec)

Heartbeat is used to determine the connection status between Peer-to-Peer devices and to ensure that the ioLogik 2500 is connected and alive (0 to 65535 sec; default = 5).



NOTE

If the heartbeat interval is set and the network between the Peer-to-Peer devices is down, the ioLogik 2500 will detect lack of heartbeat, and then disconnect the Peer-to-Peer connection.

Tolerance (Sec)

Tolerance allows you to define an additional timeout interval to wait for a heartbeat signal from Peer-to-Peer devices (0 to 65535 sec; default = 10).

Port

The listen port of the local ioLogik 2500 device for peer-to-peer function (1 to 65535; default = 9300).

Peer-to-Peer Rule Settings

With peer-to-peer communication and support for channel-to-channel mapping, the ioLogik 2500 allows simultaneous multiple target transmissions.

In a Peer-to-Peer rule, the ioLogik 2500 can be configured to receive a signal from a remote site and output the signal at the local site, allowing you to configure the remote site information by configuring the IP address, slot index (for expanded E1200 units), and module type.

Remote

- **IP Address:** The IP address of the remote device that collects and sends signals.
- **Slot Index:** An integer used to represent the remote ioLogik 2500 and its E1200 expansion units (0: the ioLogik 2500 head unit; 1 to 8: the ioLogik E1200 expansion units).
- **Module Type:** The model name of the remote device.
- **Channel Type:** The input channel type of the remote device.
- **Channel Index:** The input channel index of the remote device.

Local

- **Slot Index:** The local ioLogik 2500 or its E1200 expansion units.
- **Channel Type:** The output channel type of the local device.
- **Channel Index:** The output channel index of the local device.
- **Disconnection Mode:** The output mode when peer-to-peer disconnection occurs (options for DO: ON, OFF, or Hold Last; options for AO: manual or Hold Last).

Criterion

- **On change:** Triggers the peer-to-peer signal transmission when the status of the DI channel changes or the value of the AI channel changes by the pre-defined percentage.
- **Interval:** Triggers the peer-to-peer signal transmission when the interval time elapses (500 to 65535 ms; default = 1000).



NOTE

Up to 16 Peer-to-Peer rules can be set (a set of ioLogik 2500 + up to 8 x ioLogik E1200).



NOTE

You only need to configure peer-to-peer rules for output channels on the local ioLogik device. The peer-to-peer channels at the remote field site will be mapped to automatically.

5. Device Library

With Device Library, the operator uses IOxpress to export the configuration to devices on the network. That is, settings that were configured offline are exported over the network to online devices. This can be done either in batch mode, or on a case-by-case basis.


IOxpress can also be used to access online devices directly to check I/O status, upgrade firmware, export configurations, and restart devices.

Introduction

IOxpress provides an **online device management** user interface for ioLogik 2500 units that are deployed online, allowing you to handle all online devices with a single interface.

Online device management can be used to update/export configurations to/from multiple ioLogik 2500 devices. It provides a variety of functions to help you manage multiple devices at the same time, including:


- Locate device
- Update configuration to device
- Get configuration from device
- Update firmware
- Set device date & time
- Retrieve system log
- Restart Device
- Load Factory Default
- Change IP address
- Change Device Name



Auto-Searching for Online Devices


First Time Searching for Devices

- The first time you start IOxpress, it will open to the **Device Library** page, IOxpress will automatically display an auto-search information popup window.
- Click **Yes** to start searching for devices. Uncheck **Enable Search Reminder** if you don't want to show this message again.(This can be enabled again under **Option (Options (Search Reminder Settings.)**)
- The search information will be displayed in the Log.



Conducting another Search for Online Devices

If you would like to conduct another search for online devices, click **Search...** under the **Device** tab on the menu bar.




The Search function provides three search criteria:

1. LAN
2. WAN
3. CDA

LAN


When searching for devices on the local area network (LAN), use the filters located on the LAN tab to narrow your search to specific devices.

- By Product Series
- By Product Model
- By MAC Address
- By IP Address



WAN

For devices on the wide area network (WAN), click the WAN tab and then enter the IP address, username, and password to add the device.




CDA

Cellular Data Access is a device gateway that allows you to establish connections to ioLogik 2500 units configured with a dynamic public IP. You will need to install Cellular Data Access on a server that is using a public IP address, and the ioLogik 2500-GPRS/HSPA unit's configuration must have the Cellular Data Access function enabled. Once the Cellular Data Access and ioLogik 2500 are configured, you can use "add device by cellular data access" to add a device registered in the Cellular Data Access server. Detailed configuration instructions can be found in Chapter 6: Cellular Network Setup and Configuration (for cellular models).

After configuring the CDA, the CDA server IP and port number can be used on the CDA tab to search for devices. Follow these steps to conduct a search.

1. Type in the server's IP address and port number.
2. Click the **Connect** button.
3. Select the cellular device that you would like to connect to and click submit.

4. The selected devices have been added to the online device list, and you can start to upload/configure your devices over the cellular network.




Deployment

After online devices have been added to the online device list, you can then use deployment to deploy the online devices.

Deployment allows you to deploy multiple devices at the same time. To execute a deployment, first click **Device Library** in the left panel, and then click the drop down menu on the right to select the deployment function. Nine different functions can be used for mass deployment.

- Locate Device
- Update configuration to device
- Get configuration from device
- Update firmware
- Set device date & time
- Retrieve system log
- Restart Device
- Load Factory Default
- Change IP address
- Change Device Name




NOTE

If you do not want to change a device's network settings, uncheck the Overwrite Network Setting checkbox.

Overwrite Network Setting

In the following subsections, we describe in greater detail how to use these functions.



Update Configuration to Device


Use this function to update configurations that were completed using **Configuration Library**. The ioLogik's system configuration, including the current Click&Go Plus rule-set, can be imported and exported to the ioLogik 2500 device. You will need to know the user name and password to use this function.

The configuration can be from one of two sources:

Configurations from Configuration Library

To update a configuration completed in Configuration Library, click the **Configuration** column and select the configuration you created.

(The configuration name will be shown using the **Device Name** that was set during the offline configuration.)



Configurations from a File

You can update a configuration from a configuration file saved on your computer.



NOTE

If the device is Locked, you must log in as administrator to gain access to the ioLogik's configuration options. If you have not updated the username and password, use the defaults:

Default User Name: admin
Default password: moxa

Get Configuration from Device

You can get the configuration from an ioLogik 2500 unit and save the configuration to your PC.


Update Firmware

The **Firmware Update** tab is available after you log in as administrator. Enter the path to the firmware file or click on the icon to browse for the file. Click **Update** to update the ioLogik firmware. The wizard will lead you through the entire process, including restarting the ioLogik.


Set Device Date & Time

The ioLogik 2500 can be synchronized with PC time, or the time can be set manually.


1. Select the function “Set Device Date & Time”.



2. Select “Sync with PC” or “Manual Setting” and check the device. Then, enter the username and password.



3. Click the submit button and check whether the result is successful.



NOTE

Regardless of whether the time was synchronized with PC time or was set manually, the ioLogik 2500 will continue to connect to an NTP server periodically. The time will be updated the next time the ioLogik 2500 connects to the NTP server.

Retrieve System Log

The ioLogik 2500 will log the system's status in the device. When needed, you can retrieve the system logs and send the logs to the Moxa support team for further analysis. Since the system log is analyzed by the Moxa support team, the log will be encoded.

Restart Device

Select this command to restart a selected ioLogik 2500.

Load Factory Default

Select this command to reset all settings on the selected ioLogik, including the password and all configuration settings, to factory default values.

Change IP Address

Use this function to change the IP address of an ioLogik 2500.

Change Device Name

Use this function to change the server name.

Change IP Address and Server Name can be used to deploy the same configuration to multiple devices and change the IPs and Server names of the devices.

Web Console


Use the web console to check the device status. There are two ways to connect to the ioLogik 2500 web console.

Direct Access By Browser

The ioLogik 2500 series can be accessed using Internet Explorer (version 9 or above), Firefox, or Google Chrome to check device status. Type the ioLogik 2500's IP address in the browser's address box to access the unit.

Open Selected Device Web via IOxpress

Open the IOxpress graphical user interface and then select the device you would like to check. Click the Web Browser icon on the quick launch bar or right click on the selected device and choose **Web Console...**, to start IOxpress in the PC's default browser. In order to ensure that the information is displayed correctly, please ensure that version 9 or above of Microsoft Internet Explorer is installed on your computer.





NOTE

- Default user name: admin
- Default password: moxa

The user name and password are case-sensitive.

Web Console Functions

You can check the device status and also import/export configurations from the web console. The following section introduces how to use these web console functions.

User Interface Introduction

The web console is divided into three regions:

1. System information panel
2. Menu panel
3. Web page panel (the web page associated with the function selected in the Menu panel)



System Information Panel



The system information panel displays the ioLogik 2500's system information, including Name, Firmware versions, IP address, Click&Go status, serial number, MAC address, Connection status, and Date and Time.

Menu Panel and Web Pages

The menu panel includes the following items.

I/O Status

Click I/O Status to check the I/O status of the ioLogik 2500 and its expansion modules. The Web page panel should appear similar to figure shown at the right. The number of "slots" that appear will depend on the number E1200 modules connected to the ioLogik 2512.



- Click any of the slots (Slot-0, Slot-1, ..., Slot-8) to check the I/O status of the device.
- Use the **Locate** function to identify the physical location of the selected device. The device's RDY LED will continuously blink green.
- Use the DI/Counter channels to check the DI/Counter status and reset/start/stop the counter.

DI								
No	Name	Mode	Counter value	Trigger event	Filter	Status	Start/Stop counter	
0	DI-00	DI-DI	--	--	100 us	Off	--	
1	DI-01	DI-Counter	0	Reset	Low to High	100 us	Stop	Start Stop


- Use the DO/Pulse channels to manually control the DO/Pulse.

DO								
No	Name	Mode	ON width	OFF width	Pulse count	Status	Start/Stop pulse	
8	DIO-00	DIO-DO	--	--	--	Off	On off	
9	DIO-01	DIO-Pulse	100 us	100 us	0	Stop	Start Stop	

Cellular (ioLogik 2500-GPRS/HSPA only)

Use this function to identify the cellular connection status of ioLogik 2500-GPRS/HSPA units.

- There are four cellular connection stages. While a particular stage is in process, the icon of the stage will be green.




- The cellular information provides the IMEI and RSSI of the cellular connection.
- Once the IP and DNS are received from the ISP, the network information will be shown.
- SIM Information shows the current status of the SIM card.

Cellular Info.	Network Info.	SIMs Info.
IMEI 358625050016080 RSSI 99	IP None DNS None	SIM-1 Using Cannot Found SIM-2 Cannot Found

VPN Status (ioLogik 2500-GPRS/HSPA only)

Use this function to identify the VPN connection status of ioLogik 2500-GPRS/HSPA units.

- You can check VPN status. There are four cellular connection stages. While a particular stage is in process, the icon of the stage will be green.



Upgrade



Click this icon to upgrade the firmware. You can choose the FWR file you would like to use for the upgrade.

Import



Click this icon to import a device configuration. You can choose the config file you would like to use for the upgrade.

Export



Click this icon to export a device configuration.

Reset



Click this icon to reset the device to factory default.

6. Cellular Network Setup and Configuration (for cellular models)

In this chapter, we introduce how to set up your ioLogik 2500-GPRS/HSPA device.

IOxpress Settings for a Cellular Network

When you add an ioLogik 2500-GPRS/HSPA model, the following two functions will be available (in addition to the functions discussed in Chapter 3).

Select Network Interface

Configure your device's cellular network settings on the **Select Network Interface** page, which is located under the **Network-General** sub-page.

Select Network Interface

Cellular Only

Cellular Always On
 Cellular On Demand

By Click&Go Plus
 Wake On Call

Index	Phone Number
0	
1	
2	
3	
4	

LAN as Primary and Cellular as Backup

Dest.	www.google.com
(AOPC Server or any public URL)	
Continuous check until	3
Retry Interval	30
(10 to 600 sec(s))	

General Settings

<input checked="" type="checkbox"/> Enable Web Console	
<input checked="" type="checkbox"/> Enable Server Socket Idle Connection Timeout (sec(s))	60
Private IP for the First Expansion Module	192 . 168 . 120 . 1

Cellular Only

You can configure under what conditions the ioLogik 2500-GPRS/HSPA will connect to the cellular network. For example, the device could be triggered by a Click&Go Plus rule or by wake on call.

Cellular Always On

This mode allows the ioLogik 2500-GPRS/HSPA to always remain connected to the cellular network.

Cellular ON Demand

This mode allows the ioLogik 2500-GPRS/HSPA to conserve power by flipping into sleep mode whenever there is no need to transmit information. When in sleep mode, the ioLogik 2500-GPRS/HSPA disables the cellular connection and stays in standby mode, saving all I/O records in the data log on the SD card. The ioLogik 2500-GPRS/HSPA will only wake up when either:

1. It receives an activate message from Click&Go, or
2. It receives a call from an authorized caller phone number.

LAN as Primary and Cellular as Backup

By selecting this function, a remote destination is used in this setting to indicate if the Internet connection is still alive. The user can specify a public IP or URL and the number of retries that are allowed. If the Ethernet is disconnected, the cellular connection will be triggered as a backup.

Dest IP/URL

This option, which can be configured to either an AOPC server IP or any public URL, will be used by the device to determine whether or not it is connected to the Internet.

Continuous Check Until 3 failures

The ioLogik 2500-GPRS/HSPA continuously check its connection with the IP/URL to ensure that it is constantly connected to the internet (could incur a high cost, depending on your cellular plan).

Retry Interval

The “retry interval” is the time interval between retries.

Cellular

Cellular network settings are configured on the “cellular” page, which is located under “Network.”

General

To set up your cellular connection, click the **Cellular Settings** tab and enter your **User name**, **Password**, **SIM pin code**, and **APN** of your Cellular Provider (contact your local Cellular Service Provider for assistance).

Cellular Data Network Settings (SIM1)		Cellular Data Network Settings (SIM2)	
Username	<input type="text"/>	Username	<input type="text"/>
Password	<input type="text"/>	Password	<input type="text"/>
SIM PIN	<input type="text"/>	SIM PIN	<input type="text"/>
APN	internet	APN	internet
Band	Auto	Band	Auto
PPP Authentication	Auto mode	PPP Authentication	Auto mode
Dial AT Command	ATD*99***1#	Dial AT Command	ATD*99***1#

VPN

In this section, we explain how to set up a VPN connection for the ioLogik 2500-GPRS/HSPA.

Enable VPN

<input type="checkbox"/> Enable VPN	
VPN Tunnel Mode	Manual Key
Remote Endpoint IP	<input type="text"/>
Remote Subnet IP	<input type="text"/>
Remote Subnet Netmask	255 . 255 . 255 . 0
Local Subnet IP	<input type="text"/>
Local Subnet Netmask	255 . 255 . 255 . 0

VPN Tunnel Mode

The type of VPN tunnel policy to be used; either manual key IPsec or ISAKMP with Pre-shared Keys (PSK).

Remote Endpoint IP

Enter the **WAN IP** of the remote VPN server endpoint.

Remote Subnet IP:

Enter the remote VPN server subnet (LAN) IP of the remote network.

Remote Subnet netmask

Enter the remote VPN server subnet netmask of the remote network.

Local subnet IP

Enter the ioLogik 2500’s subnet (LAN) IP.

Local Subnet netmask

Enter the ioLogik 2500’s subnet netmask.

Manual Key

Manual Key

Incoming Security Settings

SPI	<input type="text"/>
Encryption Mode	DES <input type="button" value="▼"/>
Authentication Mode	MD5 <input type="button" value="▼"/>
Encryption Key	<input type="text"/>
Authentication Key	<input type="text"/>

Outgoing Security Settings

SPI	<input type="text"/>
Encryption Mode	DES <input type="button" value="▼"/>
Authentication Mode	MD5 <input type="button" value="▼"/>
Encryption Key	<input type="text"/>
Authentication Key	<input type="text"/>

SPI

Set the VPN manual key for incoming/outgoing SPI between 257 and 4294967295.

Encryption mode

Select the incoming/outgoing encryption mode.

Encryption key

Enter the incoming/outgoing encryption key.

Encryption mode	Length (bytes)
DES	8
3DES	24
AES 128bit	16
AES 192bit	24
AES 256bit	32

Authentication mode

Select the incoming/outgoing authentication mode.

Authentication key

Enter the incoming/outgoing authentication key.

Authentication mode	Length (bytes)
MDS	16
SHA1	20

ISAKMP/PSK

ISAKMP/PSK

ISAKMP (Key Management)

Pre-Share Key (PSK)

Perfect Forward Secrecy (PFS)

Local Identity

Identity Option

IP/FQDN/User-FQDN

ISAKMP Phase 1

Operation Mode

NAT Traversal (NAT-T)

Encryption Mode

Authentication Mode

Diffie-Hellman Group

SA Lifetime (600-86400 sec.)

ISAKMP Phase 2

Encryption Mode

Authentication Mode

Diffie-Hellman Group

SA Lifetime (600-86400 sec.)

Advanced Settings

Anti-Replay

Dead Peer Detection (DPD)

ISAKMP (Key Management)

Pre-shared key (PSK): Sets the VPN ISAKMP Pre-Shared key settings.

Perfect forward secrecy (PFS) (default = Disable): Enable or disable the Perfect Forward Secrecy. PFS as an additional security protocol.

Local Identity

Identity option: Select additional ID authentication requirements for the VPN using a specific IP Address, FQDN, or User FQDN settings.

IP/FQDN/User_FQDN: Enter an ID (IP/FQDN/User_FQDN) to identify and authenticate the local VPN endpoint.

ISAKMP phase 1

Operation mode: Select main mode or aggressive mode to configure the standard negotiation parameters for IKE Phase 1 of the VPN Tunnel.

NAT-T (default = Disable): Enabling this option will allow IPSec traffic from this endpoint to traverse through the translation process during NAT. The remote VPN endpoint must also support this feature and it must be enabled to function properly over the VPN.

Encryption mode: Select the VPN ISAKMP phase 1 encryption mode.

Authentication mode: Select the VPN ISAKMP phase 1 authentication mode.

Diffie-Hellman group: Select the VPN ISAKMP phase 1 DH group. As the DH Group number increases, the higher the level of encryption implemented for PFS.

SA life time (default = 86400): Enter the number of seconds for the VPN ISAKMP phase 1 Lifetime. This is the period of time that passes before establishing a new IPSec security association (SA) with the remote endpoint.

ISAKMP phase 2

Encryption mode: Select the VPN ISAKMP phase 2 encryption mode. **Authentication mode:** Select the VPN ISAKMP phase 2 authentication mode.

Diffie-Hellman group: Select the VPN ISAKMP phase 2 DH group. As the DH Group number increases, the higher the level of encryption implemented for PFS.

SA life time (default = 28800): Enter the number of seconds for the VPN ISAKMP phase 2 Lifetime. This is the period of time that passes before establishing a new IPSec security association (SA) with the remote endpoint.

Advanced settings

Anti-replay (default = Disable): Anti-replay is the method of not allowing an intercepted packet message to be sent to the recipient multiple times without the original sender knowing about it.

Dead Peer Detection (DPD) (default = Disable): Enable or disable Dead Peer Detection. DPD is a method of detecting a dead Internet Key Exchange (IKE) peer. It sends a DPD packet to the peer every 60 seconds under no traffic and attempts to connect normally. If the DPD packet fails 5 times the VPN will continuously re-establish a connection.

Reconnection

Carriers disconnect idle mobile device connections in order to save bandwidth for other on-line users and applications. To keep the ioLogik 2500-GPRS/HSPA always On, the ioLogik 2500-GPRS/HSPA must not only have the capability to detect the cellular connection and reconnect to the network once it is disconnected, but also needs to send out signals (ICMP package) to notify carriers that the ioLogik 2500-GPRS/HSPA is still alive.

<input checked="" type="checkbox"/> Dual SIM Failover Mode (Note: if disabled, only SIM1 is activated when two SIMs are installed.)
<input checked="" type="checkbox"/> Reconnect cellular network after address <input type="text" value="8.8.8.8"/> ping failure for 3 times
Ping Interval <input type="text" value="60"/> sec(s) (10 to 600, default: 60)
<input checked="" type="checkbox"/> Restart device after reconnection failure for <input type="text" value="1"/> hour(s) (1 to 24, default: 1)

Dual SIM Failover Mode

When the **Dual SIM Failover Mode** checkbox is selected, the ioLogik 2500-GPRS/HSPA will switch from one SIM card to the other when a connection cannot be established using the active SIM card.

If the function is disabled, only SIM1 is activated when two SIMs are installed.

Reconnect cellular network after 3 ping failures

The device will keep pinging Dest.IP/URL after an Internet connection is established. If the ping fails three times, the ioLogik 2500-GPRS/HSPA will start the GSM reconnection process.

Dest IP/URL

Can either be an AOPC server IP or any public URL for the device to check its connection with the internet.



NOTE

If using a URL, you may need to configure DNS through **Network > LAN > IP Settings**.

Ping Interval

The ioLogik 2500-GPRS/HSPA will ping the Dest IP/URL at regular intervals to check for an Internet connection.

Restart device after reconnection fails for X hours (1 to 24)

If rebooting the **Reconnect cellular network after ping failure** does not reestablish your connection, the disconnection may be caused by a higher layer communication problem. In this case, you can select **Restart device after reconnection failure** for any time interval from 1 to 24 hours. The ioLogik 2500-GPRS/HSPA will restart the device.

Port Forwarding

The ioLogik 2500-GPRS/HSPA supports port forwarding on its cellular and Ethernet interfaces for WAN-to-LAN communication. Using port forwarding, the ioLogik 2500-GPRS/HSPA allows external WAN hosts such as SCADA/HMI systems to connect to specific field devices within the LAN by linking with the ioLogik 2500-GPRS/HSPA.

Enable Port Forwarding

Enabled	Index	Protocol	Public Port	Internal IP	Internal Port
<input checked="" type="checkbox"/>	0	TCP	80	192.168.127.50	8000
<input type="checkbox"/>	1	TCP	2	0.0.0.2	2
<input type="checkbox"/>	2	TCP	3	0.0.0.3	3
<input type="checkbox"/>	3	TCP	4	0.0.0.4	4
<input type="checkbox"/>	4	TCP	5	0.0.0.5	5
<input type="checkbox"/>	5	TCP	6	0.0.0.6	6
<input type="checkbox"/>	6	TCP	7	0.0.0.7	7
<input type="checkbox"/>	7	TCP	8	0.0.0.8	8
<input type="checkbox"/>	8	TCP	9	0.0.0.9	9
<input type="checkbox"/>	9	TCP	10	0.0.0.10	10

Ethernet packages from public ports will be forwarded to the assigned Internal IP and Internal Port. In the example shown above, Ethernet packets from the ioLogik 2500's port 80 will be forwarded to 192.168.127.50:8000 (IP: 192.168.127.50; Port: 8000).

Enable Port Forwarding

Enable or disable the port forwarding function.

Index

The port forwarding rules index for identification, cannot be changed.

Protocol

Choose which Ethernet protocol will be forwarded. You can choose either TCP or UDP.

Internal IP

The destination IP that Ethernet packets will be forwarded to

Internal Port

The destination port that Ethernet packets will be forwarded to.

DDNS

The purpose of DDNS is to provide you with an alternative cost effective cellular plan. You will not need to establish a server or pay for a Static IP. Setting up DDNS allows the ioLogik 2500-GPRS/HSPA to behave like a server and perform functions such as email, ftp, etc. Regardless of whether the device has a floating IP or a private IP, the user can establish a connection with their remote device through DDNS. DDNS allows the SCADA/HMI server to establish a connection through the DDNS server to find the remote device.

Enable DDNS

Service Provider	<input type="text" value="DynDns.org"/>
Host Name	<input type="text"/>
Username	<input type="text"/>
Password	<input type="text"/>

Service Provider (default=DynDns.org)

Currently, DynDns.org is the only option available for Server address.

Host name

Enter the name you created on www.dyndns.com in this field. The ioLogik 2500-GPRS/HSPA will update the DynDNS server with this host name.

Username

This is the user name used for updating DDNS Server authentication.

Password

This is the password used for updating DDNS Server authentication.

Cellular Data Access

The **Cellular Data Access** setting is used for connecting to Moxa cellular data access utilities.

For detailed information on how to set up the cellular data access server, see the next section, **Moxa Cellular Data Access Utility**.

Enable Cellular Data Access

IP Address	<input type="text" value="0 . 0 . 0 . 0"/>
Port	<input type="text" value="9401"/>
Unique ID	<input type="text" value="0"/>
Heartbeat (sec.)	<input type="text" value="30"/>

IP address

Enter the IP address of the cellular data access server.

Port

Enter the port number of the cellular data access server.

Unique ID

The unique ID is used for remote action functions. For detailed information, refer to the Click&Go Plus User's Manual.

Heartbeat (sec.)


The heartbeat is used to determine whether or not the connection between an ioLogik device and the cellular data access server is still active.

Cellular Network Connection

The dynamic IP addresses commonly used for cellular connections make it hard for control systems to link to cellular data acquisition devices. With Moxa's MX-AOPC server, SCADA/HMI users can easily connect to field I/O devices. For web-based applications, Moxa's cellular data access utility provides an ideal way to seamlessly connect to remote cellular IO units.

MX-AOPC Server (for SCADA/HMI users)

To allow private networks to get around the connectivity issues raised by edge devices configured with dynamically assigned private IP addresses, typically operators purchase high-cost static IP addresses for each device, with IPs provided by a DDNS or VPN service purchased from an MVNO (Mobile Virtual Network Operator). Even with DDNS technology, SCADA systems need to assign resources to manage the DDNS servers. As an alternative, Moxa's Cellular remote I/O devices use Moxa's proprietary "push" technology, called MX-AOPC Server.



With Moxa's powerful MX-AOPC Server support, communications efficiency between ioLogik 2500-GPRS/HSPA devices and the central SCADA are substantially improved. Moxa's MX-AOPC Server's non-polling communications architecture supports the standard OPC protocol, but instead of requiring the SCADA to poll edge devices it allows edge devices to actively push communications to the central HMI/SCADA system, empowering the network with real time I/O updates while substantially cutting network overhead.

Unlike the requirements of a traditional OPC server (where remote I/O devices must use a static IP so they may be successfully polled), MX-AOPC Server and ioLogik products allow engineers the flexibility of configuring edge devices with dynamic IP addresses. Even when using DHCP addressing, ioLogik devices can push messages back to the OPC server, allowing wide area I/O networks using dynamic IP cellular accounts. Using traditional polling OPC applications, I/O devices cannot make use of this approach.

With DDNS (for SCADA/HMI users)

In addition to using MX-AOPC Server to register an ioLogik ioLogik 2500-GPRS/HSPA with SCADA over a dynamic IP cellular connection, you may also use DDNS to configure the device with a unique URL. The ioLogik 2500-GPRS/HSPA can be configured to register a DNS hostname (i.e. – URL) with DDNS, and thereby convert a dynamic IP to a publicized address. In this way, centralized control software will be able to connect to the remote ioLogik 2500 GPRS/HSPA without requiring a fixed IP or VPN service from a network provider.

Moxa Cellular Data Access Utility (for mobile devices/PCs)

With the Moxa cellular data access utility, you can configure the ioLogik 2500-GPRS/HSPA using the IOxpress utility over the cellular network. You can also log on to selected ioLogik 2500 devices by using a specific URL port. In this section, we explain how to use these two methods to connect devices.

Step1: Installing Cellular Data Access Utility on a server PC

Cellular Data Access Utility is a Windows utility provided for connecting and managing the ioLogik 2500-GPRS/HSPA over a cellular network. Cellular Data Access Utility can be used from anywhere on the network to monitor and configure the ioLogik 2500-GPRS/HSPA.

Downloading from Moxa's Website

Click the following link: <http://www.moxa.com/support/search.aspx?type=soft>.

Enter the name of the product you have purchased into the search bar or select it from the dropdown menu, and after navigating to the product page click on Utilities, in the middle of the page, located in the box titled Software.

Download and then unzip the file, and then run **SETUP.EXE** from that location.

The installation program will guide you through the installation process and install the software. After the installation is finished, run the software from the Windows Start menu.

Step2: Use “offline configuration” to set up the ioLogik 2500-GPRS/HSPA


Before you start using the cellular data access utility, set up the “cellular data access” function. See the [Cellular Data Access](#) section in this chapter for details.

Step3: Connect to the device over the cellular network

Using IOxpress

Connect to the cellular Data Access server using Device Library, as described below:

1. Click **Device Management**.
2. Click the **Search** icon on the quick launch bar and select the **CDA** tab.
3. Type in the server's IP address and port number.
4. Click the **Connect** checkbox.
5. Select the cellular device that you would like to connect to and then click **submit**.



6. The selected devices have been added to the online device list, and you can start to upload/configure your devices over the cellular network.

Using a browser URL

1. Check the port number in the cellular data access utility.

Once the devices are connected, the utility will automatically assign URL ports to the devices.



2. Access the device via the browser.

You can use the URL to connect to the device by typing **http://[IP address] : [Port]**.

IP Address: The IP address of the Cellular Data Access server.

Port: The port number of the device assigned by Cellular Data Access.

E.g., 192.168.17.253:20002

7. Wireless LAN Network Setup and Configuration (for wireless LAN models)

In this chapter, we introduce how to set up your ioLogik 2500-WL1 device.

Deploying the ioLogik 2500-WL1

For testing requirements, we strongly suggest that you prepare a wireless LAN adapter. After finishing the installation and configuration, you should test the ioLogik 2500-WL1 to make sure the wireless transmission is working normally.

Step 1: Set up the computer's IP address, and the connect ioLogik 2500-WL1 to a notebook or PC.

In a Windows environment, the computer's IP address can be changed in the TCP/IP settings window. Select an IP address on the same subnet as the ioLogik 2500-WL1. Since the ioLogik 2500-WL1's default IP address is 192.168.127.253, and the subnet mask is 255.255.255.0, you should set the IP address of the computer to 192.168.127.xxx.


Step 2: Use the IOxpress utility to configure the ioLogik 2500-WL1.

See the following section to learn how to use IOxpress to configure the ioLogik 2500-WL1's functions.



ATTENTION

Be sure to eliminate loops from networks that consist of wireless bridges, Ethernet switches, Ethernet links, and Wireless LAN links. If any loops exist, packets will circle around the loops and network performance will be seriously degraded. The following figure shows a network topology containing a loop.



IOxpress Settings for a Wireless LAN Network

When you add an ioLogik 2500-WL1 model to your network, the following two functions will be available (in addition to the functions discussed in Chapter 3).

Wireless LAN

Cellular network settings are configured on the “cellular” page, which is located under “Network.”

Basic

The Basic tab is used to add and edit RF type, channel width, and SSID.

RF Type

SSID

Setting	Description	Factory Default
B	Supports IEEE 802.11b only	
G	Supports IEEE 802.11g only	
B/G Mixed	Supports both IEEE 802.11b/g standards, but 802.11g will operate more slowly when 802.11b clients are on the network	B/G Mixed

Channel Width

Channel Width

Setting	Description	Factory Default
20 MHz	Select your channel width. Currently, the ioLogik 2500’s Wi-Fi connection only supports 20 MHz.	20 MHz

SSID

An SSID is a unique identifier that wireless networking devices use to establish and maintain wireless connectivity. Multiple access points on a network or sub-network can use the same SSIDs.

SSID

Setting	Description	Factory Default
Max. of 31 characters	The SSID of a client and the SSID of the AP must be identical for the client and AP to be able to communicate with each other.	MOXA



NOTE

The model name of the ioLogik 2500-WL1 is shown as ioLogik 2500-WL-XX in IOxpress, where XX indicates the country code. The country code indicates the ioLogik 2500-WL1 version and which bandwidth it uses. We use ioLogik 2500-WL1-US as an example in the following figures. (The country code and model name that appear on your computer screen may be different than the ones shown here.)

Security

The ioLogik 2500-WL1 provides four standardized wireless security modes: Open, WEP (Wired Equivalent Privacy), WPA (Wi-Fi Protected Access), and WPA2.

Security Mode

Open

No authentication, no data encryption.

For security reasons, users should NOT set the security mode to Open System, since authentication and data encryption are NOT performed in Open System mode.

WEP

Static WEP (Wired Equivalent Privacy) keys must be configured manually.

According to the IEEE 802.11 standard, WEP can be used for authentication and data encryption to maintain confidentiality. **Shared** (or **Shared Key**) authentication type is used if WEP authentication and data encryption are both needed. Normally, **Open** (or **Open System**) authentication type is used when WEP data encryption is run with authentication.

When WEP is enabled as a security mode, the length of a key (the so-called WEP seed) can be specified as 64/128 bits, which is actually a 40/104-bit secret key with a 24-bit initialization vector. The ioLogik 2500-WL1 provides 4 entities of WEP key settings that can be selected to use with **Key index**. The selected key setting specifies the key to be used as a send-key for encrypting traffic from the AP side to the wireless client side. All 4 WEP keys are used as receive-keys to decrypt traffic from the wireless client side to the AP side.

The WEP key can be presented in two **Key types**, HEX and ASCII. Each ASCII character has 8 bits, so a 64-bit WEP key contains 5 characters, and a 128-bit key has 13 characters. In hex, each character uses 4 bits, so a 64-bit key has 10 hex characters, and a 128-bit key has 26 characters.

Authentication type

Setting	Description	Factory Default
Open	Data encryption is enabled, but without authentication	Open
Shared	Data encryption and authentication are both enabled.	

Key type

Setting	Description	Factory Default
HEX	Specifies WEP keys in hex-decimal number format	HEX
ASCII	Specifies WEP keys in ASCII format	

Key length

Setting	Description	Factory Default
64 bits	Uses 40-bit secret keys with 24-bit initialization vector	64 bits
128 bits	Uses 104-bit secret key with 24-bit initialization vector	

Key index

Setting	Description	Factory Default
1-4	Specifies which WEP key is used	Open

WEP key 1-4

Setting	Description	Factory Default
	A string that can be used as a WEP seed for the RC4 encryption engine. ASCII type: 64 bits: 5 chars / 128 bits: 13chars HEX type: 64 bits: 10 hex chars / 128 bits: 26 hex chars	None

WPA/WPA2-Personal

Also known as WPA/WPA2-PSK. You will need to specify the Pre-Shared Key in the Passphrase field, which will be used by the TKIP or AES engine as a master key to generate keys that actually encrypt outgoing packets and decrypt incoming packets.

WPA (Wi-Fi Protected Access) and WPA2 represent significant improvements over the WEP encryption method. WPA is a security standard based on 802.11i draft 3, while WPA2 is based on the fully ratified version of 802.11i. The initial vector is transmitted, encrypted, and enhanced with its 48 bits, twice as long as WEP. The key is regularly changed so that true session is secured.

Even though AES encryption is only included in the WPA2 standard, it is widely available in the WPA security mode of some wireless APs and clients as well. The ioLogik 2500-WL1 also supports AES algorithms in WPA and WPA2 for better compatibility.

Personal versions of WPA/WPA2, also known as WPA/WPA-PSK (Pre-Shared Key), provide a simple way of encrypting a wireless connection for high confidentiality. A **Passphrase** is used as a basis for encryption methods (or cipher types) in a WLAN connection. The passphrases should be complicated and as long as possible. The Passphrase must have at least 8 ASCII characters, and can have as many as 63. For security reasons, this passphrase should only be disclosed to users who need it, and it should be changed regularly.

WPA/WPA2-Enterprise

WPA type

Setting	Description	Factory Default
Personal	Provides Pre-Shared Key-enabled WPA and WPA2	Personal
Enterprise	Provides enterprise-level security for WPA and WPA2	

Encryption method

Setting	Description	Factory Default
TKIP	Temporal Key Integrity Protocol is enabled	TKIP
AES	Advanced Encryption System is enabled	

Passphrase

Setting	Description	Factory Default
8 to 63 characters	Master key to generate keys for encryption and decryption	None

EAP Protocol

Setting	Description	Factory Default
TLS	Specifies Transport Layer Security protocol	
TTLS	Specifies Tunneled Transport Layer Security	TLS
PEAP	Specifies Protected Extensible Authentication Protocol, or Protected EAP	

WPA/WPA2-Enterprise

Also called WPA/WPA2-EAP (Extensible Authentication Protocol). In addition to device-based authentication, WPA/WPA2-Enterprise enables user-based authentication via IEEE 802.1X. The ioLogik 2500-WL1 can support three EAP methods: EAP-TLS, EAP-TTLS, and EAP-PEAP.

By setting **WPA type** to **Enterprise**, you can use EAP (Extensible Authentication Protocol), a framework authentication protocol used by 802.1X to provide network authentication. In these Enterprise-level security modes, a back-end RADIUS (Remote Authentication Dial-In User Service) server is needed if IEEE 802.1X functionality is enabled in WPA /WPA2. The IEEE 802.1X protocol also offers the possibility of carrying out an efficient connection authentication on a large-scale network. It is not necessary to exchange keys or passphrases.

WPA type

Setting	Description	Factory Default
Personal	Provides Pre-Shared Key-enabled WPA and WPA2	Personal
Enterprise	Provides enterprise-level security for WPA and WPA2	

Encryption method

Setting	Description	Factory Default
TKIP	Temporal Key Integrity Protocol is enabled	TKIP
AES	Advanced Encryption System is enabled	

Passphrase

Setting	Description	Factory Default
8 to 63 characters	Master key to generate keys for encryption and decryption	None

EAP-TLS

TLS is the standards-based successor to Secure Socket Layer (SSL). It can establish a trusted communication channel over a distrusted network. TLS provides mutual authentication through certificate exchange. EAP-TLS is also secure to use. You are required to submit a digital certificate to the authentication server for validation, but the authentication server must also supply a certificate.

EAP Protocol

Setting	Description	Factory Default
TLS	Specifies Transport Layer Security protocol	
TTLS	Specifies Tunneled Transport Layer Security	TLS
PEAP	Specifies Protected Extensible Authentication Protocol, or Protected EAP	

EAP-TTLS

It is usually much easier to re-use existing authentication systems, such as a Windows domain or Active Directory, LDAP directory, or Kerberos realm, rather than creating a parallel authentication system. As a result, TTLS (Tunneled TLS) and PEAP (Protected EAP) are used to support the use of so-called "legacy authentication methods." TTLS and PEAP work in a similar way. First, they establish a TLS tunnel (EAP-TLS for example), and validate whether the network is trustworthy with digital certificates on the authentication server. This step establishes a tunnel that protects the next step (or "inner" authentication), and consequently is sometimes referred to as "outer" authentication. The TLS tunnel is then used to encrypt an older authentication protocol that authenticates the user for the network.

As you can see, digital certificates are still needed for outer authentication in a simplified form. Only a small number of certificates are required, which can be generated by a small certificate authority. Certificate reduction makes TTLS and PEAP much more popular than EAP-TLS.

The ioLogik 2500-WL1 provides some non-cryptographic EAP methods, including **PAP**, **CHAP**, **MS-CHAP**, and **MS-CHAP-V2**. These EAP methods are not recommended for direct use on wireless networks. However, they may be useful as inner authentication methods with TTLS and PEAP.

Because the inner and outer authentications can use distinct user names in TTLS and PEAP, you can use an anonymous user name for the outer authentication, with the true user name only shown through the encrypted channel. Keep in mind that not all client software supports anonymous alteration. Confirm this with the network administrator before you enable identity hiding in TTLS and PEAP.

TTLS Inner Authentication

Setting	Description	Factory Default
PAP	Password Authentication Protocol is used	
CHAP	Challenge Handshake Authentication Protocol is used	
MS-CHAP	Microsoft CHAP is used	MS-CHAP-V2
MS-CHAP-V2	Microsoft CHAP version 2 is used	

Anonymous

Setting	Description	Factory Default
Max. of 31 characters	A distinct name used for outer authentication	None

User name & Password

Setting	Description	Factory Default
	User name and password used in inner authentication	None

PEAP

There are a few differences in the TTLS and PEAP inner authentication procedures. TTLS uses the encrypted channel to exchange attribute-value pairs (AVPs), while PEAP uses the encrypted channel to start a second EAP exchange inside of the tunnel. The ioLogik 2500-WL1 provides **MS-CHAP-V2** merely as an EAP method for inner authentication.

Inner EAP protocol

Setting	Description	Factory Default
MS-CHAP-V2	Microsoft CHAP version 2 is used	MS-CHAP-V2

Anonymous

Setting	Description	Factory Default
Max. of 31 characters	A distinct name used for outer authentication	None

User name & Password

Setting	Description	Factory Default
	User name and password used in inner authentication	None

Advanced

Additional wireless-related parameters are presented in this section to help you set up your wireless network in detail.

Advanced Settings

Transmission Rate

Setting	Description	Factory Default
Auto	The device senses and adjusts the data rate automatically	Auto

Transmission Power

Setting	Description	Factory Default
3 dBm to 20 dBm	The device adjusts the transmission power	10 dBm

Fragmentation threshold

Setting	Description	Factory Default
256 to 2346	Specifies the maximum size of a data packet before splitting and creating another new packet	2346

RTSthreshold

Setting	Description	Factory Default
256 to 2346	Determines how large a packet can be before the Access Point coordinates transmission and reception to ensure efficient communication	2346

WMM

Setting	Description	Factory Default
Enable/Disable	WMM is a QoS standard for WLAN traffic. Voice and video data will be given priority bandwidth when enabled with WMM supported wireless clients.	Enable

Turbo Roaming

Setting	Description	Factory Default
Enable/Disable	Moxa's Turbo Roaming can enable rapid handover when the device, as a client, roams among a group of APs.	Disable

AP Alive Check

AP alive check will check if the AP connection is still available. When this function is enabled, a check will be done every 10 ms.

AP Candidate Threshold

After the "AP alive check" declares the current access point is no longer available, the surrounding access points must have good enough connection qualities (SNR/Signal Strength) in order to be qualified as AP candidates for association.

Roaming Threshold

Determines when to start looking for new AP candidates. If the current connection quality (SNR or Signal Strength) is lower than the specified threshold, the ioLogik will start background scanning and look for next-hop candidates.

Roaming Difference

Determines if roaming should be executed. After a background scan has been triggered, the roaming will only occur if the AP candidate(s) provide a better (Roaming difference) connection quality than the current connection. If multiple access points fulfill the criteria, the ioLogik will pick the best one to roam to.

Scan Channels

You can set up Scan channels for the APs among which this client is going to roam. There are three Scan channels available.

Note that the Scan channels may need to be modified when the RF type is changed. (For example, channel 36 is not available in B, G, or B/G Mix mode.)

A. Network Port Usage

The ioLogik 2500 uses the following network ports:

Usage	Type	Port	User-Defined
Serial Tunnel Client	TCP	1	✓
FTP Client	TCP	21	✓
FTP Server	TCP	21	
Web Console	TCP	80	
SNMP Server	TCP	161	
SNMP Client	TCP	162	
Modbus Communication	TCP	502	
SMTP	TCP	587	✓
Serial Tunnel Server	TCP	4001	✓
Auto Search Function	UDP	4800	
TCP/UDP Message	TCP	9000	✓
	UDP	9000	✓
Remote Action Function	TCP	9010	
Peer-to-peer Function	TCP	9300	✓
IOxpress	TCP	10124	
AOPC Protocol*	TCP	9500	
	TCP	9900	✓

*The ioLogik 2500 series only supports MX-AOPC UA server.



NOTE

- Client refers to when the ioLogik 2500 is acting as a client to connect other services.
- Server refers to when the ioLogik 2500 is acting as a server to provide services to other devices.

B. Modbus/TCP Default Address Mappings

The following topics are covered in this appendix:

- ioLogik 2512 Series Modbus Address and Register Map
Including ioLogik 2512, ioLogik 2512-GPRS, ioLogik 2512-HSPA, ioLogik 2512-WL1
- ioLogik 2542 Series Modbus Address and Register Map
Including ioLogik 2542, ioLogik 2542-GPRS, ioLogik 2542-HSPA, ioLogik 2542-WL1



NOTE

The Modbus/TCP ID of the ioLogik 2500 Series is set to "1" by default.

ioLogik 2512 Series Modbus Address and Register Map

The table below shows the default Modbus addresses for the ioLogik 2512 series. Refer to the IOexpress Modbus/TCP Slave Setting page in Configuration Library for expansion the units' Modbus addresses.

Description	Point Type	R/W	Start Address (DEC)	Reference Address (DEC)	Total Channels	Data Type
DI Value	02: INPUT STATUS	Read only	0	10001	8	1 BIT
DI Counter Value	03: HOLDING REGISTER	Read/Write	0	40001	8	2 WORDS
DIO Value	01: COIL STATUS	Read/Write	0	00001	8	1 BIT
DIO Counter Value	03: HOLDING REGISTER	Read/Write	100	40101	8	2 WORDS
DIO Pulse Status	01: COIL STATUS	Read/Write	100	00101	8	1 BIT
Internal Register	03: HOLDING REGISTER	Read/Write	500	40501	48	1 WORDS
Float Internal Register	03: HOLDING REGISTER	Read/Write	1000	41001	48	2 WORDS
DI Counter Start/Stop	01: COIL STATUS	Read/Write	1200	01201	8	1 BIT
DIO Counter Start/Stop	01: COIL STATUS	Read/Write	1300	01301	8	1 BIT
P2P Connection Status	02: INPUT STATUS	Read only	1400	11401	16	1 BIT
Virtual Channel Value	04: INPUT REGISTER	Read only	1500	31501	10	2 WORDS
Reset DI Counter	01: COIL STATUS	Read/Write	1600	01601	8	1 BIT
Reset DIO Counter	01: COIL STATUS	Read/Write	1700	01701	8	1 BIT
Clear Safe Mode	01: COIL STATUS	Read/Write	1800	01801	1	1 BIT
BOOL Internal Register	01: COIL STATUS	Read/Write	200	00201	48	1 BIT
DWORD Internal Register	03: HOLDING REGISTER	Read/Write	1400	41401	48	2 WORDS
DI Counter Overflow Flag	02: INPUT STATUS	Read only	100	10101	8	1 BIT
DIO Counter Overflow Flag	02: INPUT STATUS	Read only	150	10151	8	1 BIT
Clear DI Counter Overflow Flag	01: COIL STATUS	Read/Write	150	00151	8	1 BIT
Clear DIO Counter Overflow Flag	01: COIL STATUS	Read/Write	250	00251	8	1 BIT
Modbus Master Status	04: INPUT REGISTER	Read only	0	30001	2	1 WORDS
I/O Expansion Status	04: INPUT REGISTER	Read only	50	30051	8	1 WORDS

ioLogik 2542 Series Modbus Address and Register Map

The table below shows the default Modbus address for the ioLogik 2542 series. Refer to the IOexpress Modbus/TCP Slave Settings page in the Configuration Library for the expansion units' Modbus addresses.

Description	Point Type	R/W	Start Address (DEC)	Reference Address (DEC)	Total Channels	Data Type
DIO Value	01: COIL STATUS	Read/Write	0	00001	12	1 BIT
DIO Counter Value	03: HOLDING REGISTER	Read/Write	0	40001	12	2 WORDS
DIO Pulse Status	01: COIL STATUS	Read/Write	12	00013	12	1 BIT
AI Scaling Value (Float)	04: INPUT REGISTER	Read only	100	30101	4	2 WORDS
AI min. Value (Float)	03: HOLDING REGISTER	Read/Write	200	40201	4	2 WORDS
AI max. Value (Float)	03: HOLDING REGISTER	Read/Write	300	40301	4	2 WORDS
Internal Register	03: HOLDING REGISTER	Read/Write	500	40501	48	1 WORDS
Float Internal Register	03: HOLDING REGISTER	Read/Write	1000	41001	48	2 WORDS
DIO Counter Start/Stop	01: COIL STATUS	Read/Write	1200	01201	12	1 BIT
P2P Connection Status	02: INPUT STATUS	Read only	1400	11401	16	1 BIT
Virtual Channel Value	04: INPUT REGISTER	Read only	1500	31501	10	2 WORDS
Reset DIO Counter	01: COIL STATUS	Read/Write	1600	01701	12	1 BIT
Clear Safe Mode	01: COIL STATUS	Read/Write	1800	01801	1	1 BIT
AI Status (0: normal, 1:BO, 2:over-ranged, 3: under-ranged)	04: INPUT REGISTER	Read only	150	30151	4	1 WORDS
AI RAW Value	04: INPUT REGISTER	Read only	1000	31001	4	1 WORDS
BOOL Internal Register	01: COIL STATUS	Read/Write	200	00201	48	1 BIT
DWORD Internal Register	03: HOLDING REGISTER	Read/Write	1400	41401	48	2 WORDS
DIO Counter Overflow Flag	02: INPUT STATUS	Read only	150	10151	12	1 BIT
Clear DI Counter Overflow Flag	01: COIL STATUS	Read/Write	250	00251	12	1 BIT
Modbus Master Status	04: INPUT REGISTER	Read only	0	30001	2	1 WORDS
I/O Expansion Status	04: INPUT REGISTER	Read only	50	30051	8	1 WORDS

C. RESTful API Default Address Mappings

The operating parameters of http should be specified in the header.

- Accept: vdn.dac.v1
- Content-Type: application/json

Supported Methods

- GET
- PUT
- OPTION

API List

RESTful API	Name	Description	Access
<code>/api/slot/0/sysInfo</code>			
<code>/api/slot/0/sysInfo/device</code>	modelName	model name	read-only
<code>/api/slot/0/sysInfo/device</code>	deviceName	device name	read-only
<code>/api/slot/0/sysInfo/device</code>	deviceDateTime	device date and time	read-only
<code>/api/slot/0/sysInfo/device</code>	deviceTimeZone	device time zone	read-only
<code>/api/slot/0/sysInfo/device</code>	deviceUpTime	device up time	read-only
<code>/api/slot/0/sysInfo/device</code>	firmwareVersion	firmware version	read-only
<code>/api/slot/0/sysInfo/device</code>	serialNumber	serial number	read-only
<code>/api/slot/0/sysInfo/device</code>	ioExpansionStatusSlot1	i/o expansion status - slot 1	read-only
<code>/api/slot/0/sysInfo/device</code>	ioExpansionStatusSlot2	i/o expansion status - slot 2	read-only
<code>/api/slot/0/sysInfo/device</code>	ioExpansionStatusSlot3	i/o expansion status - slot 3	read-only
<code>/api/slot/0/sysInfo/device</code>	ioExpansionStatusSlot4	i/o expansion status - slot 4	read-only
<code>/api/slot/0/sysInfo/device</code>	ioExpansionStatusSlot5	i/o expansion status - slot 5	read-only
<code>/api/slot/0/sysInfo/device</code>	ioExpansionStatusSlot6	i/o expansion status - slot 6	read-only
<code>/api/slot/0/sysInfo/device</code>	ioExpansionStatusSlot7	i/o expansion status - slot 7	read-only
<code>/api/slot/0/sysInfo/device</code>	ioExpansionStatusSlot8	i/o expansion status - slot 8	read-only
<code>/api/slot/0/sysInfo/network</code>			
<code>/api/slot/0/sysInfo/network/LAN</code>			
<code>/api/slot/0/sysInfo/network/LAN/1</code>	lanMac	MAC address	read-only
<code>/api/slot/0/sysInfo/network/LAN/1</code>	lanIp	IP address	read-only
<code>/api/slot/0/sysInfo/network/WLAN</code>			
<code>/api/slot/0/sysInfo/network/WLAN/1</code>	wlanMac	MAC address	read-only
<code>/api/slot/0/sysInfo/network/WLAN/1</code>	wlanIp	IP address	read-only
<code>/api/slot/0/sysInfo/network/Cellular</code>			
<code>/api/slot/0/sysInfo/network/Cellular/1</code>	cellularImei	MAC address	read-only
<code>/api/slot/0/sysInfo/network/Cellular/1</code>	cellularIp	IP address	read-only
<code>/api/slot/0/sysInfo/network/Cellular/1</code>	cellularRssi	RSSI	read-only
<code>/api/slot/0/sysInfo/modbustcpmaster</code>			
<code>/api/slot/0/sysInfo/modbustcpmaster/device</code>			

RESTful API	Name	Description	Access
/api/slot/0/sysInfo/modbustcpmaster/device/0	modbusTcpMasterDeviceStatus	Modbus/TCP Master - Device Status (0: Disconnected; 1: Good;)	read-only
/api/slot/0/sysConfig/restartDevice	restartDevice	restart device	read-write
/api/slot/0/io/di			
/api/slot/0/io/di	diIndex	DI - index	read-only
/api/slot/0/io/di	diName	DI - name	read-only
/api/slot/0/io/di	diMode	DI - mode (0: DI, 1: Counter)	read-only
/api/slot/0/io/di	diStatus	DI - DI mode - status (0: OFF, 1: ON)	read-only
/api/slot/0/io/di	diCounterValue	DI - Counter mode - value	read-write
/api/slot/0/io/di	diCounterStatus	DI - Counter mode - status (0: Pause, 1: Run)	read-write
/api/slot/0/io/di	diCounterOverflowFlag	DI - Counter mode - overflow flag (0: Normal, 1: Overflow)	read-only
/api/slot/0/io/di	diCounterOverflowFlagClear	DI - Counter mode - clear overflow flag (1: Clear)	read-write
/api/slot/0/io/di/0/diStatus	diStatus	DI - DI mode - status (0: OFF, 1: ON)	read-only
/api/slot/0/io/di/0/diCounterValue	diCounterValue	DI - Counter mode - value	read-only
/api/slot/0/io/di/0/diCounterReset	diCounterReset	DI - Counter mode - reset to initial value (1: RESET)	read-write
/api/slot/0/io/di/0/diCounterStatus	diCounterStatus	DI - Counter mode - status (0: STOP, 1: START)	read-write
/api/slot/0/io/do			
/api/slot/0/io/do	doIndex	DO - index	read-only
/api/slot/0/io/do	doMode	DO - mode (0: DO, 1: Pulse)	read-only
/api/slot/0/io/do	doStatus	DO - DO mode - status (0: OFF, 1: ON)	read-write
/api/slot/0/io/do	doPulseCount	DO - Pulse mode - count	read-only
/api/slot/0/io/do	doPulseOnWidth	DO - Pulse mode - ON width (unit: 1 ms)	read-only
/api/slot/0/io/do	doPulseOffWidth	DO - Pulse mode - OFF width (unit: 1 ms)	read-only
/api/slot/0/io/do	doPulseStatus	DO - Pulse mode - status (0: STOP, 1: START)	read-write
/api/slot/0/io/do/0/doStatus	doStatus	DO - DO mode - status (0: OFF, 1: ON)	read-write
/api/slot/0/io/do/0/doPulseCount	doPulseCount	DO - Pulse mode - count	read-write
/api/slot/0/io/do/0/doPulseStatus	doPulseStatus	DO - Pulse mode - status (0: STOP, 1: START)	read-write
/api/slot/0/io/dio			
/api/slot/0/io/dio	dioIndex	DIO - index	read-only
/api/slot/0/io/dio	dioName	DIO - name	read-only
/api/slot/0/io/dio	dioMode	DIO - mode (0: DI, 1: DO)	read-only
/api/slot/0/io/dio	dioDiMode	DIO - DI - mode (0: DI, 1: Counter)	read-only
/api/slot/0/io/dio	dioDiStatus	DIO - DI - DI mode - status (0: OFF, 1: ON)	read-only
/api/slot/0/io/dio	dioDiCounterValue	DIO - DI - Counter mode - value	read-write
/api/slot/0/io/dio	dioDiCounterStatus	DIO - DI - Counter mode - status (0: Pause, 1: Run)	read-write
/api/slot/0/io/dio	dioDiCounterReset	DIO - DI - Counter mode - reset to initial value (1: Reset)	read-write

RESTful API	Name	Description	Access
/api/slot/0/io/dio	dioDiCounterOverflowFlag	DIO - DI - Counter mode - overflow flag (0: Normal, 1: Overflow)	read-only
/api/slot/0/io/dio	dioDiCounterOverflowFlagClear	DIO - DI - Counter mode - clear overflow flag (1: Clear)	read-write
/api/slot/0/io/dio	dioDoMode	DIO - DO - DO mode - mode (0: DO, 1: Pulse)	read-only
/api/slot/0/io/dio	dioDoStatus	DIO - DO - DO mode - status (0: OFF, 1: ON)	read-write
/api/slot/0/io/dio	dioDoPulseCount	DIO - DO - Pulse mode - count	read-only
/api/slot/0/io/dio	dioDoPulseOnWidth	DIO - DO - Pulse mode - ON width (unit: 100 us)	read-only
/api/slot/0/io/dio	dioDoPulseOffWidth	DIO - DO - Pulse mode - OFF width (unit: 100 us)	read-only
/api/slot/0/io/dio	dioDoPulseStatus	DIO - DO - Pulse mode - status (0: Stop 1: Start)	read-write
/api/slot/0/io/dio/0/dioDiStatus	dioDiStatus	DIO - DI mode - status (0: OFF, 1: ON)	read-only
/api/slot/0/io/dio/0/dioDiCounterValue	dioDiCounterValue	DIO - Counter mode - value	read-write
/api/slot/0/io/dio/0/dioDiCounterReset	dioDiCounterReset	DIO - Counter mode - reset to initial value (1: RESET)	read-write
/api/slot/0/io/dio/0/dioDiCounterStatus	dioDiCounterStatus	DIO - Counter mode - status (0: STOP, 1: START)	read-write
/api/slot/0/io/dio/0/dioDoStatus	dioDoStatus	DIO - DO mode - status (0: OFF, 1: ON)	read-write
/api/slot/0/io/dio/0/dioDoPulseCount	dioDoPulseCount	DIO - Pulse mode - count	read-only
/api/slot/0/io/dio/0/dioDoPulseStatus	dioDoPulseStatus	DIO - Pulse mode - status (0: STOP, 1: START)	read-write
/api/slot/0/io/relay			
/api/slot/0/io/relay	relayIndex	Relay - index	read-only
/api/slot/0/io/relay	relayName	Relay - name	read-only
/api/slot/0/io/relay	relayTotalCount	Relay - total count	read-only
/api/slot/0/io/relay	relayCurrentCount	Relay - current count	read-only
/api/slot/0/io/relay	relayCurrentCountReset	Relay - reset current count (1: Reset)	read-write
/api/slot/0/io/relay	relayMode	Relay - mode (0: Relay, 1: Pulse)	read-only
/api/slot/0/io/relay	relayStatus	Relay - Relay mode - status (0: OFF, 1: ON)	read-write
/api/slot/0/io/relay	relayPulseCount	Relay - Pulse mode - count	read-only
/api/slot/0/io/relay	relayPulseOnWidth	Relay - Pulse mode - ON width (unit: 1.5 sec)	read-only
/api/slot/0/io/relay	relayPulseOffWidth	Relay - Pulse mode - OFF width (unit: 1.5 sec)	read-only
/api/slot/0/io/relay	relayPulseStatus	Relay - Pulse mode - status (0: Stop 1: Start)	read-write
/api/slot/0/io/relay/0/relayStatus	relayStatus	Relay - Relay mode - status (0: OFF, 1: ON)	read-write
/api/slot/0/io/relay/0/relayPulseStatus	relayPulseStatus	Relay - Pulse mode - status (0: STOP, 1: START)	read-write
/api/slot/0/io/relay/0/relayPulseCount	relayPulseCount	Relay - Pulse mode - count	read-only
/api/slot/0/io/ai			
/api/slot/0/io/ai	aiIndex	AI - index	read-only
/api/slot/0/io/ai	aiName	AI - name	read-only
/api/slot/0/io/ai	aiMode	AI - mode (0: 0-10 V, 1: 0-20 mA, 2: 4-20 mA burnout, 3: 4-20 mA, 4: ±10 V)	read-only

RESTful API	Name	Description	Access
/api/slot/0/io/ai	aiValueRaw	AI - raw value	read-only
/api/slot/0/io/ai	aiValueScaled	AI - scaled value	read-only
/api/slot/0/io/ai	aiValueScaledMin	AI - minimum scaled value	read-only
/api/slot/0/io/ai	aiValueScaledMax	AI - maximum scaled value	read-only
/api/slot/0/io/ai	aiResetMinValue	AI - reset minimum value (1: Reset)	read-only
/api/slot/0/io/ai	aiResetMaxValue	AI - reset maximum value (1: Reset)	read-only
/api/slot/0/io/ai	aiStatus	AI - status (0: normal, 1: burnout, 2: over range, 3: under range)	read-only
/api/slot/0/io/ai	aiBurnoutValue	AI - burnout value	read-only
/api/slot/0/io/ai/0/aiValueRaw	aiValueRaw	AI - raw value	read-only
/api/slot/0/io/ao			
/api/slot/0/io/ao	aoIndex	AO - index	read-only
/api/slot/0/io/ao	aoMode	AO - mode (0: 0-10 V, 1: 4-20mA, 2: 0-20 mA)	read-only
/api/slot/0/io/ao	aoValueRaw	AO - raw value	read-write
/api/slot/0/io/ao	aoValueScaled	AO - scaled value	read-only
/api/slot/0/io/ao/0/aoValueRaw	aoValueRaw	AO - raw value	read-write
/api/slot/0/io/rtd			
/api/slot/0/io/rtd	rtdIndex	RTD - index	read-only
/api/slot/0/io/rtd	rtdSensorType	RTD - sensor type	read-only
/api/slot/0/io/rtd	rtdValueEngineeringMultiplied	RTD - engineerinig multiplied value	read-only
/api/slot/0/io/rtd	rtdValueScaled	RTD - scaled value	read-only
/api/slot/0/io/rtd	rtdValueScaledMin	RTD - minimum scaled value	read-only
/api/slot/0/io/rtd	rtdValueScaledMax	RTD - maximum scaled value	read-only
/api/slot/0/io/rtd	rtdResetMinValue	RTD - reset minimum value (1: RESET)	read-write
/api/slot/0/io/rtd	rtdResetMaxValue	RTD - reset maximum value (1: RESET)	read-write
/api/slot/0/io/rtd/0/rtdValueEngineeringMultiplied	rtdValueEngineeringMultiplied	RTD - engineerinig multiplied value	read-only
/api/slot/0/io/tc			
/api/slot/0/io/tc	tcIndex	TC - index	read-only
/api/slot/0/io/tc	tcSensorType	TC - sensor type	read-only
/api/slot/0/io/tc	tcValueEngineeringMultiplied	TC - engineerinig multiplied value	read-only
/api/slot/0/io/tc	tcValueScaled	TC - scaled value	read-only
/api/slot/0/io/tc	tcValueScaledMin	TC - minimum scaled value	read-only
/api/slot/0/io/tc	tcValueScaledMax	TC - maximum scaled value	read-only
/api/slot/0/io/tc	tcResetMinValue	TC - reset minimum value (1: RESET)	read-write
/api/slot/0/io/tc	tcResetMaxValue	TC - reset maximum value (1: RESET)	read-write
/api/slot/0/io/tc/0/tcValueEngineeringMultiplied	tcValueEngineeringMultiplied	TC - engineerinig multiplied value	read-only
/api/slot/0/io/bir			
/api/slot/0/io/bir	birIndex	BIR - index	read-only
/api/slot/0/io/bir	birName	BIR - BOOL internal register name	read-only
/api/slot/0/io/bir	birValue	BIR - BOOL internal register value	read-write
/api/slot/0/io/wir			
/api/slot/0/io/wir	wirIndex	WIR - index	read-only
/api/slot/0/io/wir	wirName	WIR - WORD internal register name	read-only

RESTful API	Name	Description	Access
/api/slot/0/io/wir	wirValue	WIR - WORD internal register value	read-write
/api/slot/0/io/dwir			
/api/slot/0/io/dwir	dwirIndex	DWIR - index	read-only
/api/slot/0/io/dwir	dwirName	DWIR - DWORD internal register name	read-only
/api/slot/0/io/dwir	dwirValue	DWIR - DWORD internal register value	read-write
/api/slot/0/io/fir			
/api/slot/0/io/fir	firIndex	FIR - index	read-only
/api/slot/0/io/fir	firName	FIR - float internal register name	read-only
/api/slot/0/io/fir	firValue	FIR - float internal register value	read-write
/api/slot/0/io/vc			
/api/slot/0/io/vc	vcIndex	VC - index	read-only
/api/slot/0/io/vc	vcName	VC - virtual channel name	read-only
/api/slot/0/io/vc	vcValue	VC - virtual channel value	read-write
/api/slot/0/p2p/rule	p2PIndex	Peer-to-Peer - Index	read-only
/api/slot/0/p2p/rule	p2PRuleStatus	Peer-to-Peer - status (0: Idle/Disconnection, 1: Running)	read-only

Response Code

MOXA Status Code	MOXA Description	HTTP Status code	Description	User Message
101	Unsupported Version	400	Bad Request	The content version specified in the request is not supported.
201	Invalid Json Format	400	Bad Request	The json format in the request is invalid.
202	Invalid Node Value	400	Bad Request	One of the node values is invalid.
203	Wrong Channel Order	400	Bad Request	The I/O channels are disordered.
300	Content Failed	400	Bad Request	One of the channel content in the request could not be set. Please refer to the detail information.
301	Content Failed To Set	400	Bad Request	The content in the request could not be set. (invalid value)
N/A	Successful Request	200	OK	Successful requests.
N/A	Resource Not Found	404	Bad Request	This resource cannot be found.
N/A	Unsupported Http Method	405	Method Not Allowed	The specified HTTP method is not supported
N/A	Internal Error	500	Internal Server Error	The server encountered an internal error. Please retry the request.